




CHECKMATE[™]




DISPLAYS[™]



17" & 19" RETRO COMPUTER MONITOR
USER MANUAL

CHECKMATE AT A GLANCE

WHAT YOU SEE IS WHAT YOU GET



NOTE: Can be used to control pods, and more!


MAIN REMOTE




RF REMOTE for TV TUNER on APPY'S RETRO SCALER



SLOT ZERO



APPY'S RETRO SCALER OPTIONAL POD



PORTS



RCA/PHONO



USB



HDMI



VGA 31KHz



3.5 JACK



POWER




SCART/Péritel/EuroAV



RF/AERIAL



S-VIDEO



9-PIN

NOTES

*Yes, we know it's an odd order but the engineering dictated the arrangement.

** Monochrome modes only work with RGBi input.

*** RGBi, also CGA, EGA, and Appy's Commodore C128.

NOTE: The Appy's Retro Scaler is an optional add-on pod and not included with the standard system.

[HTTPS://CHECKMATEDISPLAYS.COM/](https://checkmatedisplays.com/)

Contents

Foreword by Phil South

Chapter 1: Introduction

Chapter 2: Important information for getting started and things to know

Chapter 3: Day to Day usage

Chapter 4: Inputs selection and explanation

Chapter 5: Overview of the monitor features

Chapter 6: Advanced Features in the pipeline

Chapter 7: The XRI Backplane

Chapter 8: Slot 0 main controller

Chapter 9: Appy's Retro Scaler

Chapter 10: Checkmate iMIGA 3k Pod

Chapter 11: Assembling / Disassembling the Monitor

Chapter 12: Appy's technical details

Chapter 13: GBS Control usage

Chapter 14: RF User guide

Chapter 15: Mister Fitting Instructions

Chapter 16: My Mister install photo gallery

Chapter 17: Meet Appy, a profile of our Chief Engineer

Chapter 18: A thank you message to all involved in this project

Chapter 19: Kickstarter Backers

Chapter 20: My Patreon's who have supported me for years.

Chapter 21: Main companies involved

A Window to the Past

Foreword by Phil South
Former journalist and professional old guy

All those years ago in 2018 when Steve offered to press a little cash into my sweaty little hand for the honour of writing an introduction for the Checkmate A1500+ case user manual, I was more than delighted to oblige. Not only was I, and am I, a massive fan of Checkmate products, I'm all for anything which feeds The Community. So, here I am again.

Now I'm not talking about the community in general, like when people talk about "society". No, I'm talking specifically about the Retro Computing Community here, you steely eyed souls who've weathered decades of indifference to your hobby from software and hardware developers alike. Anything which puts new technology in your hands is fine by me, and the Checkmate IPS Retro Monitor is so much more than just a new widget which makes life a bit easier. No, it's a whole new platform which supports retro computer fans in everything they do, be it consoles or computers, be it gaming or personal productivity. That's not nothing.

And shall I tell you what else is not nothing? The way The Community got behind this project and supported it to the hilt, not just with your hearts and minds but with something more tangible and unequivocal: cold hard wads of cash. You backed it with your wallets, and that means a lot. Here in my remote bolthole in the mountains, I looked on in awe as the Kickstarter campaign not only survived but thrived. I've not seen anything like it, and I've seen some things, I can tell you.

Like a science fiction window, through the Checkmate IPS Retro Monitor you can look into the past and the future, it unlocks so many gorgeous old computing machines which were previously unusable. It's thrilling and it makes them look so darn good on screen. Plus it opens up new ways to recreate them too, via emulation of both hardware and software in modules that you can add to the case. With this tool in your possession you can revive and renovate old devices which had been effectively cut off from the mainstream. You can connect with your past in a new and refreshed way. You can join together again around machines which had all but lost their community spirit and bring them laughing their heads off into the 21st Century.

For my part I can't wait to see what you do with this fabulous monitor, what you'll configure it to do. I'm sure you will surprise both me and yourself. But what it gives us most of all as a community is a future. It makes the old, new, the lost, found and the obsolete relevant again. And as a professional old guy that's a notion I can fully get behind.

Have fun.

Phil South, In the South of Welsh Wales, 2024



Chapter 1:

Introduction

Checkmate 19"/17" IPS Retro Monitor Overview

What we are building is a modular display platform to take us into the future of retro computing and gaming or as we say, "Yesterday's Technology Tomorrow". It's the base on which to build your own future proof display solution based on what you need, and with great build quality and good looks. And it's flexible and upgradable enough for it to last you a lifetime.

CRT displays of the kind we all grew up with are terrific displays, but they come with a price. They are not modern tech and as such they are expensive and difficult to maintain, like classic pinball machines or arcade games. We knew we had to come up with a better, more future proof solution going forwards and what we've designed is the Checkmate Retro Styled Modular IPS Display platform. Modular inputs and modular outputs.

Overview

Retro machines usually output RF, composite, SVideo or maybe RGB at 15khz, and so to get you started all models have the two composite inputs in the main controller and are able to accept composite in PAL/NTSC and 15khz compatible, interlaced or non interlaced.

Appy's Retro Scalar

For RGB signals we needed to convert that 15khz signal to a 31khz one, compatible with the VGA input of the main board, which is the standard for high quality and stable displays, i.e. none of that annoying interlace flicker.

We do this by using a frame buffer and custom circuitry that stabilises and holds an individual video frame long enough to work at 31khz. That's pretty neat if we say so ourselves.

Good points

This means that the image quality is great, better in a lot of cases than the old CRT's which had awful flicker between scan lines, the result of the old 15khz displays (may they rest in peace). Also up to 1280x1024 resolution is available natively, which looks really great. Other useful resolutions like 1024x768, 800x600, 720x576 and 640x480 are also available, either scaled or unscaled and with a user selectable 5:4 or 4:3 aspect ratio.

This improves the display for productivity apps that used interlace to get the most data on the screen, and I know for me personally this would have been a real game changer back in the day. What this means is, unless you are playing games or demos, you will have a better experience.

Downsides

Note: these are listed separately in this manual under the heading "Future features in the pipeline" (See chapter list).

Overall

Mostly we think you will notice the bright colours and great viewing angles of these monitors and being able to use Appy's amazing Retro Scalar to give you access to a wealth of different inputs: RGB Scart, EGA, CGA, RGBi, Scart Composite, Component, RF* (TV aerial) and SVideo* inputs supporting PAL and NTSC. And all inputs are easy to use and fully configurable with the Node-Control unit, via a web browser.

**We should note here that the RF and SVideo only supports 60hz regardless of input due to chips we use rather than going high priced custom chips. The other inputs all support 50hz and 60hz. The RF goes through Appy's Retro Scalar, but the SVideo is diverted to one of the internal HDMI inputs. Over time we will improve this as new chips become available. Or we could just design our own FPGA input boards like the great RetroTink systems, but to be honest this is more than the price of the monitor for high end versions. We'll ponder that one and get back to you.*

Chapter 2:

Important information for getting started

1. The pods each have independent power switches so they can be isolated, although the Slot 0 switch turns them all off regardless of the position of Slot 1 and 2 switches. *Essentially when Slot 0 is switched on then power will go through to any pod with the power left in the ON position.*
2. Pressing the front power button puts ONLY the Slot 0 main controller into standby mode, just so you are aware.
3. The front small round buttons are useful if you don't have the remote control. From left to right they switch input sources, modify monitor menu and volume up and down. However, best to use the remote control.
4. If you have Appy's Retro Scalar, then you can press the VGA button to toggle round active signals plugged in and working. It is best to have only one connected at a time, but feel free to experiment. Pressing the Channel Up/Down button toggles around the VGA signals regardless of if they are connected and powered.
5. If you have the RF input, you will notice you have a second remote control for it. Please be aware that at present when using the normal remote, it can trigger options in the RF menu. It's our intention in future to have a combined remote, of course, but we added the RF as a free bonus late in the project, so it still has some teething troubles. We hope you appreciate the free RF input with the Svideo upgrade though.
6. The HDMI out is a fantastic feature that was added to all monitors to facilitate external capture. Be aware however because it intercepts the final output to the panel it is exactly the same resolution as the IPS panel and not the input being sent to the monitor, so 1280x1024 at 50/60hz, and as such not all capture cards will understand that old mode. Also if you have our own HDMI → USB capture device you can select that as the input for your capture software. Set it to 1280x1024 and 50/60hz (or whatever is appropriate for your input).
7. If at any point you need to update the panel controller software, download the firmware file (MST_56.bin) and put into the root folder of a Fat32 formatted memory card or USB stick. It only works in one USB port on the monitor, looking from the rear, the right USB port. Power down the monitor and restart it and the upgrade process will happen automatically. DO NOT turn off the power during this process! The front light will flash on and off, and


when complete it will reboot. Once it's installed, delete the firmware file from the USB stick to prevent re-using it accidentally.

Chapter 3:

Day to Day usage

Remote Control

All users will have the main remote, but if you also have the SVideo/RF input option then you will have a separate RF remote. I'll explain why shortly. For now let's focus on the main remote.



This is mostly self explanatory, if you ever owned a TV, but here are some key

points:

Power, this puts the main Slot 0 controller into sleep mode, any other pods will still be running and consuming power. This is a good thing if you are working on something and just want the display turned off. Otherwise use the power switches at the rear accordingly. Remember the bottom switch turns off everything.

Display Info, This displays the current input source and resolution and indicates if it is either 50hz or 60hz.


Input Source

This lists all main inputs in the menu.

Please view the Inputs section for more details.

By default HDMI1 is always the main HDMI input next to the HDMI Output, but HDMI5 could be displayed as anything between HDMI2-6

VGA as standard is the rear 15 pin external VGA input. Please read the [VGA](#) and [Appy's Retro Scalar](#) sections for more information about VGA input switching.




Auto Scan, this is not what you might think. This is to help you with the HDMI switcher if you have the 5 way input. (If you don't then it will merely switch between HDMI1 external and HDMI2 internal.) You must select an HDMI source to use this menu!

By default the HDMI switcher is set to manual, so each time you press the HDMI button it toggles through HDMI1-6.



If you press the right arrow this will change it to Auto Scan. This senses when something is plugged in or activated and switches automatically. Try this to see if it suits you.



Channel (VGA)

This up and down toggle is programmed to allow you to manually switch through the VGA modes on *Appy's Retro Scalar*. When you navigate with the VGA button, the Scalar will try and sense a signal and lock to it. You will see the OLED display reset. With the channel up and down, you are manually switching through, and be aware it take two presses to switch each channel.

VGA Switching pattern in order

RF Mezze Board
Slot 2 Channel 2
Slot 1 Channel 2
Slot 2 Channel 1
Slot 1 Channel 1

(With Slot 1 and 2 switching between what is plugged into the referenced Slot.)

"Channel" is if the board plugged into the Slot has 2 VGA channels (as does "Appy's Retro Scaler") with Channel 1 being RGB, and channel 2 is SCART.

Some boards may just have the one VGA signal out, and this will be outputted on selection of that slot no matter which channel. So it may seem to be repeated through switching but only because it is outputting on both channels.

Slot 0 Menu options

Press the menu button on any source and you will have access to these menus. Please note that they remember different settings for groups of inputs, so AV has settings, then HDMI etc.


Picture Menu

This is the one you will use the most.

Picture mode has 4 options, Standard, Soft, Vivid and User. The User option can be modified to taste.

Colour temperatures are Medium, Warm, Cool and User.

Noise and MPEG Noise reduction are not really used except for media playback.



Aspect Ratio

Note: This monitor has square pixels

We talk a lot more about this later in the manual. Suffice it to say this panel is 1280x1024 pixels which makes it 5:4 for fullscreen.

All the other modes have black bars above, below or on the sides as required.

Point to point literally means say a 720x576 pixel display would be placed in the middle with 1:1 pixels and not scaled to fit.



VGA Set Up

This allows you to tweak the settings on a VGA input.

Obviously the monitor does a lot with VGA so this is the last tweak in the system.


Read up on BGS-Control later in the manual if you have *Appy's Retro Scalar*.



Sound setup

This section is obviously for setting sound modes to Standard, Movie, Music, sports and user. User is configurable as usual.

You can also turn on surround sound to make the most of the angle of the speakers.



Time details


Fairly self explanatory.



Other Menu Options

Be careful changing language unless you can read it. Quite hard to get back if not.

Blue Screen changes the back ground colour, black tends to work best hence this is default.



Chapter 4:

Power Supply Input

We use a custom power connector cable so as not to accidentally connect our power to any other devices.

It supplies 12v at 2amps and 5v at 5amps, therefore you must only ever use the monitor's proprietary power supply with a Checkmate Display.

Internally on the backplane are 5v and 12v power feeds that can be used to power your projects internally.


IMPORTANT: Due to the large number of mains plug connectors around the world and to save confusion with this, the initial Kickstarter batch, we are not including the mains lead that connects the Power pack to the mains socket.

Inputs/Outputs selection and explanation

You have obviously purchased this monitor with the promise of all the inputs you could ever need, so here is a list of the input ports, what they can accept and the kind of quality you can expect.

A very important thing to note is that if you want to video record for your content or stream live then the HDMI output duplicates exactly what is on the panel, including audio, and as such can save expensive converters that can cost more than this monitor. (Of course these external converters may be higher end conversions like the RetroTink devices.) Of course no other converters can allow you to play the game/application in real time on the correct monitor live, whilst also outputting to your recording system, unless using some Ninja skills in OWB.

Composite Video/Audio



Composite is compatible with 15khz video signal in PAL 50hz and NTSC 60hz.


Quality of composite

By its very nature, composite is a compromise as all of the colour signals go down one cable and are mixed. Of course the best RGB quality breaks the colour signals over three cables. Also not all composite signals are as good as others; like the Apple II range that does not have the best quality composite signal, up to some of the Amigas that need the capacitors replacing etc.

The Slot 0 circuitry is good at giving the best quality possible (under the circumstances) and stabilising any interlace video signals. So if a computer is used in interlace mode then flicker is usually stabilised, non interlace will probably look excellent.

There are two AV inputs on Slot 0. These have the Yellow composite video input and a red/white audio left/right connectors. These two are named AV1 and AV2 in the monitor menu source selection. On the remote control the TV button is mapped to AV2 and the AV button to AV1.


There is also a composite available through the Scart socket on Appy's Retro Scalar. By default this is mapped to AV3 by having 3 blocks joining the three pairs of AV3 pins near the slot fingers. There is an AV4 option as well but best leave as AV3 unless you have a good reason. Also, if the blocks are covering AV3 and AV4, just remove from the ones that are not required.



Finally on the backplane there is AV3 & AV4 video/audio lines so that these can be picked up here and mapped to the Source on the menu.

AV4 is spare so that any board that plugs into the backplane can map composite to this input and be controlled by the remote.

SVideo




If you have the Appy's Retro Scalar board then hopefully you ordered the SVideo upgrade. This was originally meant to be a stand alone boxed converter that would take up the third Pod space but due to help from the makers of this unit we managed to add this to the Scalar on the Mezzo board that originally had the Component connectors. However, the same company make an RF converter and so we added this as well.

Two things to be aware of, firstly unlike the other inputs on the Scalar Mezzo board which send the signals through VGA onto the backplane bus, the SVideo has an HDMI connector which then connects to one of the internal HDMI inputs. This is to use the best chip for the conversion and get the best quality without very high price custom chips.

The second thing to be aware of is that the output is only in 60hz regardless of whether it has 50hz or 60hz coming in. This is not ideal technically, but to be honest 90% of people would not notice if I did not tell them.

We have tried to find the best quality budget SVideo converter and we did find it, but it cannot compete with high end custom FPGA products like the Retro Tink which cost up to as much if not more than this entire monitor and are aimed at the top 5-10% of users.

RF Input (TV Tuner)




As a last addition and at no extra cost to the SVideo option we were able to add a TV tuner input so that old consoles and video players can be connected.

This needs a separate remote control that is included specifically for this, and hopefully later we can get this integrated into one remote control for everything. It was a choice, of including it for free with the remote or not having at all, so I hope you can see the benefit of having it.

Please note that the quality relies on the RF output from your machine, we have tested with Atari 2600 which looks great. My video recorder output looks great also. However, our experience with the RF output from a Commodore 64 and C128D was noisy, but when we took the composite from the C64 plugged into an RF generator test unit the quality was amazing. So please be aware, a good signal is crucial and to be honest you are better using composite if available.

This is part of the SVideo Mezze board for the *Appy's Retro Scalar*. Unlike the SVideo section we were able to make it work through the VGA/backplane bus and therefore not waste a precious internal HDMI input.

Component



The *Appy's Retro Scalar* Mezze boards have a component input and this is as accurate to true RGB you can get, and looks great through the monitor. There is a standard Mezze board that only has component, and the optional SVideo/RF board that also has component.

It supports 15khz video at 50hz PAL and 60hz NTSC inputs and benefits from the TrueView chips stabilisation and low latency.

Amiga computers and some others have RGB to component converters but you are better off using RGB to Scart for the best quality.

Component is not used a lot but it is there if you need it now.

CGA / EGA and RGBi



RGB DB 9-Pin

This is an additional part of *Appy's Retro Scalar* which was the reason Appy and I first met to add this to the project. It is absolutely necessary if you have a very old PC with CGA or EGA or maybe a Commodore 128 that has an RGBi output which is basically the same.

This benefits from the TrueView chip and the GBS-Control firmware that makes this work great. It took some custom chips and firmware to add this by Appy. (Thanks again Appy.)

In its present form it cannot do 350/400 lines but the usual 320x200, 640x200 etc work great and maybe in the future we can support more lines.

This runs at 15khz and other frequencies can vary.

You will notice on the rear some switches for the 9 pin input only. This converts the display to mono output and you can choose the colour you want, to create an old school mono monitor feel.

External VGA input on Slot 0



The secret sauce if you like to this product is that we use the VGA video as standard on this monitor in most cases. This is because it suits a lot of vintage products either directly at native VGA 31khz frequency or going through the *Appy's Retro Scalar*. Once in there we frame buffer the 15khz signals and

double the frequency to 31khz, then inject them into the VGA input with the use of discrete digital switches and arbitration.

VGA can handle 50hz, 60hz, and higher, but we use mostly 50hz PAL and 60hz NTSC.

The back plane uses VGA signals which include R/G/B/H-Sync/V-Sync and the associated stereo audio input from the rear. Appy has made firmware that handles all video switching so that only one VGA feed is entered to the Slot 0 controller and displayed.

Theoretically there can be the main external VGA on the rear of Slot 0 controller, and then one or more on each Pod, which the arbitration firmware juggles.

You will notice on *Appy's Retro Scalar* that sometimes you see at the top of the monitor display in big letters, RGB or SCT. This indicates which is in use, the RGB from the CGA/EGA/RGBi 9 pin port, or the SCT on the rear Scart port.


All of this is handled with the VGA button on the main controller, you will notice if you have the OLED display at the front that it gets reset each time you change the VGA channel. This is because it is switching two actual lines at a time, but pressing the Channel up/down steps through individually.

VGA Audio in




Next to the VGA input is this 3.5mm stereo input port which takes the external stereo audio source used on ANY device that feed audio into the VGA input, Scalar or other potential Backplane VGA inputs. Some like the Scart have their own, but this allows a separate audio feed into the VGA source.

Stereo Audio phono output



These phono outputs allow access to the active audio signal externally, to put into mixers or recorders, or maybe even a higher end amplification system.


Stereo Headphone Socket



This is on the rear of Slot 0 and obviously allows connection of headphones.

However, there is a connector on the backplane that will allow connection of an audio lead to mount at the front. This is not included at time of writing.

HDMI connectors



If you did not purchase the HDMI switch option then you have the following.

- 1 x External HDMI1
- 1 x Internal HDMI2
- 1 x External HDMI Output

If you purchased the 6 way HDMI option you have the following

- 4 x External HDMI 1,2,3,4 inputs in the source menu
- 2 x Internal HDMI 5/6 inputs
- 1 x External HDMI Output next to the USB sockets

These can all handle HD resolutions up to 1920x1080p, but they will all be scaled to 1280x1024 which is the resolution of the panel. These can be at 50hz PAL or 60hz NTSC inputs or even up to 75hz.


The HDMI Output is very useful for Streamers and video editors as it creates a 1280x1024 resolution at 50hz or 60hz depending on what is being displayed. It

is crucial to understand it is perfectly duplicating the 1280x1024 panel pixels and is really useful for streaming and converting while playing content and games.

Some capture cards do not understand 1280x1024 and so will not record it, this is why there is an optional HDMI-→USB3 device we offer with this monitor that will support it.

The HDMI output also encodes the Stereo Audio that is playing at the same time.

Scart input – Appy’s Retro Scalar



Scart was a universal connector in a lot of countries and we support this connector in the following ways:

Firstly it is connected to Appy’s Retro Scalar and as such expects a 15khz video signal running at 50hz PAL or 60hz NTSC. Other frequencies may be possible but that is the one we promise.

RGB Video and stereo audio are used and that is the best quality, this gets routed through Appy’s Retro Scalar and converted into VGA at 31khz.

However, we also route the Composite video and stereo audio through either the AV3 or AV4 ports mentioned in the Composite section. Please read that section for more details.

USB inputs



The Slot 0 main controller has two USB inputs which in the menu source are obviously USB1 and USB2.

These can use a USB memory drive formatted in FAT32 to enable media playback on the monitor. Obviously as the monitor is 5:4 aspect ratio, any wide screen video content will appear with black bars above and below.

You can also play high quality music through the built in speaker, which whilst not ultimate HiFi quality do a very decent job at reproducing sound, and even have an optional surround setting.

The other thing they are used for is updating the Slot 0 controller firmware by putting a file into the root of the drive and then power cycling. (See firmware update for details.)

One final thing they can do is act as an external 5v power source for external devices.

Chapter 5:

Overview of the monitor features

Design

This monitor was designed to be 5:4 and 4:3 aspect ratios to be more in keeping with the look of the old monitors we all remember. 4:3 mode has thin black bars above and below the display.

While our platform isn't intended to be a CRT replacement, of course not, we've tried as far as possible in developing this platform to design it sympathetically. We hope you agree that our monitors will look good on top or beside any of your old computers or consoles.

It doesn't stop with the look and feel though, with the new hardware expansion possibilities we've baked in you can go beyond what is possible with normal panels and most CRT's.

Form and Function

Looks are important but having the physical case depth of a CRT when there's nothing functional to fill it is just pointless and cumbersome and expensive to ship. Using our plug in modules, called pods, we expand the base or core system. We hope that in future (as has happened with our previous Kickstarter for the Checkmate desktop computer cases) users will eventually begin to develop and build their own products for our platform.

Why not a CRT?

We get asked this a lot, and as an owner of a lot of CRT's myself I know the attraction. Short answer we'd love to, but the reality is you cannot get CRT tubes anymore. I thought at one stage we had found a couple of suppliers who advertised on the internet, but they were old sites and unavailable. Old and unavailable basically says it. We had to find something more practical and future proof.

Modular System

As we said above our monitors have a modular design that allows users to upgrade functionality and input types as required. You can even make them into an AIO or "All In One" computer by attaching a small form factor computer like the MiSTer, Raspberry Pi or any other SBC or FPGA solutions inside the case.

What is a Retro monitor?

How did we choose the specification for this display platform? All users have different ideas about this but for us, as users, they are as follows:

Look Good - When placed on top of a computer or next to a console it must look right, not retro for its own sake but reproducing the DNA of historic devices.

Great Sound - With the built in German designed 4" speakers these can outperform most monitor speakers.

15khz, 50hz and 60hz - These monitors automatically support 15khz modes in component, composite and RGB scart with our Scalar Pod. They also switch between the Pal 50hz and NTSC 60hz modes automatically.

5:4 and 4:3 Display options - They must support both 5:4 and 4:3 aspect ratios to match existing old system displays. Inputs are the Secret Sauce. Crucially they must be able to cope with the 15khz video modes which no longer exist in modern mainstream panel technology. This is the main reason why our monitors are so important.

Standard Input Pod selection - The standard core unit comes with HDMI, VGA, and 2 x Composite inputs (240/480p and 288/566p). These inputs all scale and stabilise any interlace flicker instantly without any frame buffer. Composite and component are 15khz compatible as well as 50/60hz i.e. PAL/NTSC.

XRI Backplane

XRI = eXpandable Retro Interface.

This is a part introduced by Appy that saved so many potential connecting cables and transformed this product from something only for electronics comfortable people, to a usable consumer product for anyone.

Now, it has not got rid of all the cables, but the main ones like the panel backlight, speakers, button bar, i2c cables all are pre connected to the XRI back plane. So if you add a board design for the XRI and is designed around the VGA input then all you do is plug and play.

We will release all of the connections and interface information to any interested customer. Some of this information is detailed later on in this manual.

Pods

These are a way of expanding the functionality of the whole system. There are three actual bays but one is taken by the slot 0 pod, which as the name implies must ALWAYS be in the bottom slot and which is the main controller.

Pods designed around the XRI interface should need no cables if designed well, however, some may need to not use the XRI interface, or need additional cables, or use one of our developer support boards for internal connections.

We have two Pods to start with:

Appy's Retro Scalar

Well this is the most important one and is our main upgrade to the standard controllers inputs.

Checkmate iMIGA 3k (iMIGA trademarked)

This is our custom FPGA board designed firstly to recreate the custom Amiga chips but also provide a true 68000 DIP socket to allow normal 68k chips or 68020/030/040/06 accelerators to be connected.

Raspberry Pi4 and Pi5 fitting pods

We have a pod kit that enables the simple fitting of an SBC (Single Board Computer) into the monitor at the same time as being the perfect retro system. One of the most popular, budget friendly and supported are of course the Raspberry Pi computers.

MiSTer FPGA based SBC fitting kit

We have a fitting kit for one of the best and authentic ways of simulating retro computers, consoles and arcade machines via an FPGA using the Terasic DE10 Nano based MiSTer system.

There is not the scope to explain this fully in this manual, but for now just take our word for it, it is the best.

Chapter 6:

Future features in the pipeline

Whilst we have created a monitor that we believe will please the most people in the retro world, a lot of people are concerned with the minutiae of differences between flat panels and CRT's, which as I said before otherwise are no longer available or would be impossible to make now.

Latency

CRT's have almost zero latency. These panels, while around 1/60 sec (or 16ms) or around a frame of latency, is not 0ms. It is important to understand however that retro games ran at 30-60fps, or about 32-16ms per frame. So in that world a 1 frame of latency on our panels is not noticeable, to most eyes. (See later section where I shoot that comment down in flames.)

15khz

Old monitors mostly run at 15khz frequency and few mass market panels (i.e. affordable) can match this rate. Most run at a minimum of VGA frequency which is 31khz, basically double. So in order to make this work frame buffering and scan doubling needs to happen, which it does in our *Appy's Retro Scalar*. This has the benefit of stabilising the horrible interlace flicker, but also can in some cases create artefacts as objects move un-interlaced.

We are hoping to have the new unicorn panel address this issue via Arcooda in Australia, natively supporting 15khz but naturally at a much higher cost.

Pixel blending

Modern panels have almost perfect pixels where CRT's tend to blur the edges of the pixels. What this means is a lot of old game developers used to design the graphics with this in mind to create a form of analogue anti-aliasing. Modern panels highlight this (in a not ideal way) by making it too clean. This is tricky to fix sadly, but you never know. We're looking into it.

Frame rate

Does this monitor support 50hz and 60hz? It fully supports these refresh rates. The only exception to this is the RF and SVideo module. These were designed around existing conversion chips that were selected for quality and cost, but at this point they only work at 60hz output, so any 50hz input will be converted to 60hz. It's a high priority for us to offer an upgrade that fixes this, but for now we figure most people will be more than happy with this, if they even

notice it. Those unhappy with it I hope understand this improvement will come later, but at an additional cost as the conversion chips will likely be much more expensive to make. We'll keep you posted.

Backlight strobing

OK, back to the higher than 60fps comment. I was accosted by a young enthusiastic German once at an Amiga show in Mönchengladbach in 2023. He decided to announce to me that he would not buy my monitor because it was garbage. Bit personal. Now, these are occasions you can go one of two ways, but I am old and experienced so I waited to hear him out. He said it has to do with nearly all panels lack a feature called strobe backlighting. This from Google:

"Backlight strobing will shorten the time the image is held in the same place, making the movement much more natural to observe for the eye. For this to work, the response time of the pixels need to be fast, so the picture is fully refreshed and clear for each flash."

IPS panels give a bright, colourful display at any angle, but take longer to refresh, so there is no time to have a 120mhz display with black frames between each image to remove the effect, i.e. Back light strobing. This is something I want to work on in the future but will require new controller and much more expensive panels with probably poorer side viewing, which need to be addressed.

Be aware, I had to look for a good few seconds to notice it. Once you do though, then you get it. Fair enough.

I asked him to point me to research where I could learn more, but turns out as I suspected he just wanted to abuse this product for lacking something quite esoteric, and as usual with this kind of person had nothing more useful to contribute. I thought I would mention it anyway as a potential new feature. To be continued.


Future

Speaking of which, as always products are in the end always a bit of a compromise; these are ideas that can come with a much more expensive monitor (or upgrade) later in this product's life cycle. I hope you can take this information in the way it was meant, that's to say information.

Chapter 7:

XRI Backplane overview

This is a very important part of the project. It's literally the backbone, the objective of making the product more user friendly. We do this by removing as many connecting cables as possible and then most of the necessary ones connect direct to this board.

This board has many connectors, here is an explanation		
5v white power 12v black power		USB 5v Power
Slot 2		USB 5v Power
5v White power		Headphone
Slot 1		Right Speaker connector
Left Speaker connector		Front power switch
Slot 0, main controller only works here.		
Cable connectors in order – OLED, i2C dial, Panel backlight, front button bar and Infra Red		


We will provide detailed information later on in this manual for the backplane and how if you feel like it you can develop your own products to work with it.

Chapter 8:

Slot 0 – main controller board

As the title says, this is board zero, the origin, most important board. This is the main video controller card and interfaces directly with the IPS panel. We took an existing AV friendly controller and with the help of the manufacturer we added more functionality than it had originally. Plus we added our own VGA card switching functionality and made it work with our backplane, again to rationalise the rats nest of cables that used to connect it all together. On top of this the board is now high quality four layer like the main cards (not the Mezzo boards) and this ensures excellent signal quality and grounding.

Please note a lot of the white connectors shown may not be in the final board as they are not needed now that all users are using the back plane. Future versions may have some removed.



Inputs in order from left to right.

USB 1 / 2, HDMI Out, HDMI1 in, VGA, VGA audio in, headphone out, Power in, Power switch

USB inputs

There are two inputs that can both be used for attaching USB drives for video, sound and picture playback. Both can be used as external (low current) 5v power for devices. Note: looking at them from the back, the one on the right is the one to use for firmware updates.

HDMI Output

This is a very special feature on this device. The way it works is to split the signal going to the IPS panel and convert that to HDMI and then output it precisely matching what is on the panel. This means it is always 1280x1024 50/60hz, so your capture software needs to be able to support this mode. If you purchased our HDMI-USB converter then you will be able to use that.

This feature enables YouTubers and other streamers to record and stream as they play or work on the monitor, reproducing and converting perfectly any input on screen to a capture.

External VGA input

This is a true VGA 31khz input and will not accept any 15khz modes. If you want to use 15khz then you need to use the *Appy's Retro Scalar* board which interfaces with the VGA system, switching as needed with the remote controls, VGA button and channel select.

VGA Audio input

This is the audio input for the External VGA port, but also feeds the entire VGA video path that includes the *Appy's Retro Scalar* board. This keeps the audio in one place for the entire retro video system (VGA line).

Stereo headphone jack

This is a stereo headphone socket. Remember also on the backplane is a 2 pin header if you want to run a socket to the front of the monitor for convenience. The key thing to remember is plugging in the headphone jack will mute the built in speakers

Power connector

This is a highly customised power block and automatically works in the 110v and 234/240v regions. It has a special 4-pin connector to ensure it is not compatible with anything else and should only be used with this monitor.

We do not include a cable because there are too many different standards dictated by the country of origin, but the good news is they are easily available.

The 4 pins are: 5v, 12v and ground. It is rated at 12v and 2 amps, and 5v and 5 amps, which is enough for most products you may want to fit internally.

Raspberry Pi5

Please note this is not a USB-PD power supply so if you fit a Pi5 the unit will run but complain that there is a maximum 600mA of power to external devices. This is outside our control, I blame Raspberry Pi, but fortunately there is plenty of power connectors internally for devices that need higher current.

Power Switch

Self explanatory but you will notice that all Pods use the same type of switch, except the one on the Slot 0 board which is the master power switch. All pods can be disabled individually by turning off their switch.

Front power button

This button only puts Slot 0 to sleep mode, it has no effect on the other pods, this is by design so you can leave the other pods running while monitor is in sleep mode, but you must remember this as they are still drawing power.


Mezze boards

There are two Mezze board choices: the first is just 2 x "Composite, Left/Right" Audio connector plus a stereo output phonos, the second adds a five way HDMI switcher.



AV2 – Left/Right/Composite, AV1- Left/Right/Composite, Stereo L/R audio output

HDMI Switcher version



Inputs in order from left to right.

Top right – HDMI-5, HDMI-6

Lower- AV2 – Left/Right/Composite, AV1- Left/Right/Composite, Stereo L/R audio output, HDMI-4, HDMI-3, HDMI-2

Chapter 9:


Appy's Retro Scalar board

This board was originally based on the GBS8200, but due to noise issues we redesigned it from the ground up using the TrueView chip and the Scalar Control Node. We also added Scart RGB, Scart composite, EGA, CGA, RGBi, SVideo and RF inputs.

This is the main card

The black jumper blocks at the top left selects if Scart composite is AV3 (default) or AV4 in the main menu selection.

The GBS Control Node is on the right (see GBS section later in this manual).




Connectors and switches from left to right:

Scart RGB/Composite/Audio, Mono colour select, Mono Off/On, CGA/EGA/RGBi Brown fix, CGA/EGA/RGBi input, power switch.

Note: Standard Mezz board has only Component Inputs.

This is the SVideo/RF optional board



Inputs from left to right:

Top right, HDMI output for the SVideo board, connect to internal HDMI in.

Bottom, RF (Aerial), Component Red/Green/Blue, SVideo in, Svideo Audio L/R

Important: SVideo to HDMI

The RF video signal goes into the VGA path through the backplane, whereas the SVideo goes to an HDMI output, to give the best quality, and this is plugged into the internal Slot 0 HDMI input. Depending on which Slot 0 Mezze board you have, we will usually connect to HDMI-2 (default Mezze) or HDMI-6 and this is simply to keep ribbon clear of the backplane sockets.


Remember: Both these output at 60hz regardless of the input, this is why we can supply them inexpensively around £45 for both as opposed to the £250+ of other systems for just the SVideo.

GBS-Control Node


This is a very special part of our system that also allows *Appy's Retro scalar* to have low latency and great programmability.

This is the module that contains the firmware created by Robert Neumann in 2017. It was originally developed to improve the performance and quality of the very low cost GBS-8200 series of boards.

<https://ramapcsx2.github.io/gbs-control/Wiki/>



Originally this (below) was how the monitor scalar was placed into the Slot 1 or Slot 2 position and joined together with about 5 cables.



The GBS 8200 was good and offered a very low cost way of connecting retro computers to a VGA monitor by upscaling. However, it suffered from noise, due to its two layer design and layout, but also more importantly – latency.

The GBS-Control firmware disables the GBS-8200 processor firmware and replaces it with Robert's custom version in the NodeMCU. This transforms the latency performance of the original GBS-8200. Sadly it could not cure the

noise. The noise was fixed by the final design of our board that used the TrueView chip and memory and built on a 4 layer board.

Controlling the NodeMCU

There are two ways to do this, and note these are not exhaustive tutorials.

Firstly, we have preset a few setups to help you get started and these can be controlled by the jog dial and OLED at the bottom left of the monitor. Just select Presets from the menu and then try the presets numbered 1-7. Preset 1 is the default and set for a standard SCART setting. To activate the preset press the dial. The different presets are clearer when looking at the web server section. Wait, what?






Yes, the cool thing about the NodeMCU is that it has a built in Wi-Fi station and Web Server that you can connect to.



To do this open your Wi-Fi setting and join the access point "GBSControl"

The default password is "qqqqqqqq"

Open <http://gbscontrol> (or <http://gbscontrol:80>) (or <http://gbscontrol.local>) in a browser.

As I said this is not a tutorial, but these images can show what is available to modify these settings if you wish to.

<p>Presets</p> 	<p>Picture scale/move</p> 	<p>Display effects</p> 
<p>Advanced settings</p>	<p>Access point & Backup</p>	




Chapter 10:

Checkmate iMIGA 3k (iMIGA trademarked)

This is our custom FPGA board designed firstly to recreate the custom Amiga chips but also provide a true 68000 DIP socket to allow normal 68k chips or 68020/030/040/06 accelerators to be connected. However, it also allows the amazing PiStorm 500 to be plugged in and to run at unheard of speeds whilst also giving RTG graphics! I won't lie this is very cool.

More details as soon as we have finished them, but they are already running great.



Chapter 11:

Assembling / Disassembling the Monitor

This section is for guidance and completeness only because of course you will have received your unit fully assembled. Take this as a guide to how we assemble our units in case you need to disassemble yours at a later date.

Step 1 – Assemble Stand

Step 2 – Fit stand to rear panel base

Step 3 – Fit speakers and cables to rear panel

Step 4 – Fit metal chassis – Rear screws fixing

Step 5 – Fit metal chassis – Front screws fixing

Step 6 – Assemble buttons to button bar and fix OLED panel

Step 7 – Fix button bezel to chassis

Step 8 – Fix side card rails both sides

Step 9 – Fit Backplane circuit board to inside on metal chassis

Step 10 – OLED, Jog Dial, Button bar and speaker cables to the backplane

Step 11 – connect speaker cables to the backplane

step 12 – Connect IPS panel backlight cable to bottom left rear side












Step 13 – Mount 19" panel to the front of the chassis

Step 14 – Connect the panel backlight cable to the bottom of the Backplane


Step 15 – Mount 19" bezel to rear panel

Step 16 – Insert Slot 0 board into backplane, connect panel control cable

Step 17 – Fix 2 x Blank panels


	1	M5 Nylon locking Nut Stand assembly		7	Anodised M4 Allan Key bolt Speaker Assembly and Rear panel mount to chassis
	2	Stainless Steel,16mm OD,1.2mm Wire Size,9mm Compressed Length,30mm Free Length Stand assembly		8	Pozi drive/Pan Countersunk head M4 x 8mm Metal chassis to rear panel interior
	3	25mm Washer M6 hole Stand assembly		9	Pozi drive/Pan head/Countersunk M3 x 6mm Plastic part to plastic parts
	4	Pozi drive / Flange Head M5 x 30mm bolt stand assembly		10	Pozi Drive/Flange head/Countersunk M3 x 8mm Fit Bezel to rear panel
	5	M3 Rear pod mount frame bolt thumb screw		11	M4 Pozi / Flange head x 25mm Stand to Rear panel bolt
	6	M4 Nylon Locking Nut Speaker Assembly and fit stand to rear panel			

Step 1 Assemble Stand



Step 2 Fit stand to rear panel base

Four x item 4 bolts through stand into rear panel and fixed with item 1 nuts.




Step 3 Fit speakers and cables to rear panel


Using 4 x part 6 and 7, fix to side of rear panel
Repeat on opposite side.




Step 4
Fit metal chassis – Rear screws fixing




Step 5
Fit metal chassis – Front screws fixing




Step 6
Assemble buttons to button bar and fix OLED panel




Step 7
Fix button bezel to chassis



Step 8
Fix side card rails both sides




Step 9
Fit Backplane circuit board to inside on metal chassis




Step 10-12
OLED, Jog Dial, Button bar and
speaker cables to the backplane



Step 13
Mount 19" panel to the front of the
chassis




Step 14
Connect the panel backlight cable to the bottom of the Backplane



Step 15
Mount 19" bezel to rear panel




Step 16-17
 Insert Slot 0 board into Backplane,
 connect panel control cable
 Fix 2 x Blank panels



Chapter 12:

Appy's Technical section



Header To Mezzanine PCB



Slot_0 Mezze Interface

This is a 16 Way Pin Header for connecting to the Slot_0 Mezze board, the pins consist of main AV signals and also control signals for the HDMI Switcher also on the Mezze board.


AV1/AV2

AV1/AV2
Signal

Pin	Signal	Description	Pin	Signal	Description
1	GND	Ground	9	AV1	Audio/Video1 VIDEO
2	+5V	Supply	10	AV1_LIN	A/V1 Audio Left In
3	NC		11	AV1_RIN	A/V1 Audio Right In
4	GND	Ground	12	AV2	Audio/Video12 VIDEO
5	L-OUT	Audio left OUT	13	AV2_LIN	A/V2 Audio Left In
6	R-OUT	Audio Right OUT	14	AV2_RIN	A/V2 Audio Right In
7	+5V	Supply	15	HDMI_OUT	Redundant U/S
8	GND	Ground	16	U_IR	Infra-Red Signal

Descriptions

HDMI2 In




HDMI2 In

LVDS Interface



Front Panel Button Interface



Button Bar Connector

If you are using the Slot_0, connected to the XRI Backplane, this connector is not required and should not be connected. Otherwise, it is used for connecting the manual buttons that are on the front of the monitor.

Button Bar
Signal


Pin	Signal	Description
1	CH+	Channel Up
2	CH-	Channel Down
3	MENU	Show Menu
4	SOURCE	Change Source
5	VOL -	Volume Up
6	VOL +	Volume Down

Pin	Signal	Description
7	GND	Ground
8	LED_G	Show Green Stdb y Led
9	LED_R	Show Red Stdb y LED
10	POWER	Sleep/Awake Slot_0
11	GND	Ground
12	U_IR	InfraRed Signal
13	IR_VCC	InfraRed Power

Descriptions

Panel Back Light Voltage Selection

**** ONLY ALTER THIS IF YOU REALLY KNOW WHAT YOU ARE DOING!
You Will Damage your Panel. ****



Back Light Voltage Selector

Using our standard Panel, leave this set to 5V, using the shorting tab, if using any other Panel, please refer to its technical specifications. Only 12V, 5V and 3V can be selected. **Note: Changing this will void your warranty, fair warning.**

Speaker Connections Left and Right




These are to be used, only if you are not connected to the XRI Backplane, and connect the Slot_0 PCB to the monitors speakers.

The XRI – Appy's Retro Scalar

Appy's Retro Scalar, or "scaler" as that's what it is, adds a great number of inputs, but also enables further features and inputs through its Mezz interface. The board uses only the 5V from the XRI Backplane, but also passes 12v through to the Mezz interface. With the 5v, a further 3.3v and 1.8v are generated through onboard LDO Regulators.

At the heart of the board, it is powered by the TVIA TrueView TV5725 scaler chip, which people may know has been used on the GBS line of scalers. However, twinned with its 64Mb of SDRAM, the board also features the GBS-Control node, (which replaces the TV5751 Firmware by Robert Neumann) which is known as GBS-control, a continuation of previous work by dooklink, mybook4, Ian Stedman and others.



Appy's Retro Scalar board

Other features that are part of the scaler section, is a separate external clock generator, Si5351A controlled by I2C feeding direct to the TV5725 external clock input, and through the I2C onboard bus, feeding the XRI Backplane. An external OLED screen and JOG dial (a rotary Encoder) can be added for manual control of the Scalers settings.

The scaler function is only one feature of the *Appy's Retro Scalar* board, although it takes mainly SCART video/audio (with composite), Component (on Mezzes) or RGB video in and scales it to be VGA compatible.

The scaler board also has a number of video switching circuits for handling several Video channels, as well as a comprehensive RGBi / CGA / EGA conversion and colour control.

For the SCART and RGB video signals, there is a video switch controlled by the XRI_Slot_0 controller allowing selection of which input, is outputted to the scaler function. There is also a separate video input to the scaler, which is dedicated for Component input, although there is not enough room for a component 3xSocket on the Scalar board, there will be one on Mezzes boards for this input.

The scaler has a Xilinx CPLD on board, this handles the RGBi / CGA / EGA inputs. The boards then takes the digital input and creates an Analogue RGB output to the scaler. This CPLD has colour control as part of its firmware, this allows for several useful features, which are Brown Fix and Mono-Colour mode.

The brown mode, is used to replicate a circuit that used to be in CRT monitors, to modify the Dark Yellow from a mucky yellow to a Brown colour. The mono colour mode, allows you to convert the analogue RGB colours, to individual shades of Grey, Green, Amber or Blue, by using a 2 position DIP switch to select between them.


On-board Connections

The scaler board, has two socket interfaces, one for the GBS-Control node and the other for a connection of a Mezzanine (Mezzes) board. The GBS-Control node is a 30pin sub-PCB containing the ESP8266 for taking over the firmware of the TV5751, the interface uses 2 x 30 way 2x15 2.54 pitch header sockets. The Mezzes interface is a 2 x 15 2.54 pitch header socket.




The ESP Control Node

The ESP socket



On-Board Interface



Interface Pinout

Mezze Interface



Mezze Pin Header Interface

Pin	Signal	Description
1,3,5,7	VGA Sel	VGA switch control
9	Audio Left	VGA audio from Mezz
11	Audio Rgt	VGA audio from Mezz
13	VGA BLU	Blue VGA Signal from Mezz
15	VGA GRN	Green VGA Signal from Mezz
17	VGA RED	Red VGA Signal from Mezz
19	H_SYNC	VGA Hoz. Sync from Mezz
21	V_SYNC	VGA Vert. Sync from Mezz
23, 24	+5V	+5 Volt supply to Mezz
29, 30	+12V	+12 Volt supply to Mezz
2	COMP-Y	Component Luma & Sync
4	PB/CB	Component Blue
6	PR/CR	Component Red
10	IR_IN	IR Pulses from IR Receiver
14, 16, 18, 20, 22	RGB2	Reserved for future use
8,12,25, 26, 27,28	GND	Ground return

Header Pin Description


SCART AV Out Selection



AV Selection Headers

If the signal connected Via SCART is also an AV signal through the Video in-line (i.e. not just C-Sync signal but composite), then connecting shorting tabs across either one of these 6 pin headers, to select which AV channel, will display the SCART AV Signal.

Rear Connections and Switches











Rear Connections and switches

The above figure shows the rear of the Scalar board, without rear panel. A description of each of the items are described in the following:

- | | | | |
|----|------------------|---|--|
| 1. | Yellow LED | - | +12V power is available on-board |
| 2. | Red LED | - | +5V power is available on-board |
| 3. | Blue LED | - | +3V3 power is available on-board |
| 4. | SCART | - | SCART input socket |
| 5. | DIP Switches | - | Mono-Colour select, see table below... |
| 6. | Mono Select | - | Switches RGB mode to mono-colour display
Down position is ON |
| 7. | Brown Fix Select | - | Selects whether to apply Brown fix or not
Down position is ON |
| 8. | RGBi/CGA In | - | 9way d-sub socket for RGBi and CGA |
| 9. | PCB Power | - | Switch Power on / off to main Scalar board. |

Mono-Colour Selection

SWITCH POSITION S	Colour
	GREY 
	GREEN 
	AMBER 
	BLUE 


Mono-Colour Shades

The XRI – Backplane

The backplane is crucial to making the monitor as expandable and as cable-free as it can possibly be. This also allows a hassle-free method for adding new Pods.

Having the XRI, or eXpandable Retro Interface, inside your monitor gives you room for two additional Pods as well as the bottom slot, the Slot_0 controller, which handles all the video switching for the other two slots.

Here you can see the backplane and its connectors. There are two types of connectors, system and user. If you buy your monitor with the backplane included (all future monitors will include it as standard) they will already be assembled into the monitor. The next paragraph will go through these steps in detail in case you need to assemble it yourself, or need to make some modifications.



The overall backplane.

The System Connections

The system connections are all positioned on the PCB below the Slot 0 edge socket, these all connect to specific places within the monitor housing.

GBS-C Connections

There are two connectors under the slot 0 socket, on the left side, labelled I2C1 and R_EN1, with individual signal labels describing each pin.





Fig ##.2 GBS-C Connectors

I2C1 is for connecting to an OLED display allowing a separate visible screen for displaying GBS-C information. The R_EN1 connects to a Rotary Encoder that allows the control of the menu system of the OLED for changing settings of the GBS-Control board. These will only work when *Appy’s Retro Scalar Pod* is installed in the monitor.

I2C1			R_EN1		
Pin	Signal	Description	Pin	Signal	Description
1	SDA	Signal Data	1	GND	Ground
2	SCL	Signal CLK	2	+5V	5v supply
3	GND	Ground	3	D3	Switch
4	+5V	5v supply	4	D5	Data
			5	D7	Clock
I2C1 Signal Descriptions			R_EN1 Signal Descriptions		

Panel & Button Bar Connections

There are two connectors under the slot 0 socket, on the right side, labelled BL1 and CN4, with individual signal labels describing main pins.



Panel Display Connectors

BL1 is the main power to the display backlight, with CN4 connecting to the front control button bar, and IR sensor.

BL1			CN4		
Pin	Signal	Description	Pin	Signal	Description
1	RED	Power	1	NC1	Not Connected
2	RED	Power	2	NC2	Not Connected
3	BLK	Ground	3	MNU	Menu
4	BLK	Ground	4	SRC	Source
			5	VL-	Volume Down
			6	VL+	Volume Up
			7	GND	Ground
			8	LDG	LED
			9	NC3	Not Connected
			10	1/O	Standby Power On/Off
			11	GND	Ground
			12	IR	Infra-Red Signal
			13	I_VC	Infra-Red Power
BL1 Signal Descriptions			CN4 Signal Descriptions		

Audio Connections

On the backplane there are 2 Speaker Headers, for connection to the internal monitor speakers, one left and the other Right.

There is also BPHP1 (Back-Plane Headphone connector), If you intend to use the Headphone socket on Slot_0 then leave this un-connected, and also with a Shorting Tab across the 2 pin header which allows audio through to Slot_0 head Phones.

If you have a built in headphone socket on the Monitor then wire the Socket to this Connector using a 4 Pin plug, and remove the shorting tab from the 2 Pin Header, to allow audio out through internal Monitor Headphone audio Jack.

Speaker Connectors

Internal Head-Phone Connector

SPK1 / 2

Pin	Signal	Description
1	R-	Right Neg
2	R+	Right Pos


CN4 Signal Description

BPHP1

Pin	Signal	Description
1	HPR_A	Right Audio Neg
2	HP_RTN	Hot Plug Return
3	HPL_A	Left Audio Neg
4	GND	GND

SPK1 & SPK2 Signal Descriptions

Standby Connector





Front Standby Power Switch

This is used for the connector of the non-latching Front Power Button, to switch the Slot_0 system in and out of Standby Mode. Please note this only puts the Slot_0 controller to sleep, any other boards in slots 1 or 2 are still awake and using power.


The User Connections

The user connections are for enabling external modules to be powered by the main monitor power supply, through the backplane, allowing users to connect to the 5V supply, or the 12V supply.

5 Volt Supply Connections



12 Volt Supply Connector



The XRI Protocol Revision 1


This section will cover in detail the XRI Protocol which is implemented through the Backplane and controlled by the Slot_0 Controller. Hopefully with this information developers who want to can create their own pods to slot into the monitor, to add their own interface or application.

The Internal Connector

This is a 98 way PCB Edge connector slot, split into 4 pin labels, with A1 to A31 and C1 to C18 on the bottom edge, and B1 to B31 and D1 to D18 along the top edge. It is shown in the figure below.




As can be seen there is a keyed divider between A & B to C & D pins. This then will house a POD, with a matching edge connector, to simply slide in. The card edge connector is shown below, and a full description of pod sizing and design, is explained later on in this section.



The backplane connects each of the signals from Slot_0 to Slot_1 and Slot_2, although Slot_0 connections are slightly different to Slot_1 and 2 and therefore, the Slot_0 Controller must only be ever used in Slot_0 also no other card should be inserted in to Slot_0.


Here is the schematic for the connection for **SLOT_0 ONLY**



Connections Specific To SLOT_0

Looking at the bottom row, from left to right, here follows a description of each connection that is specific to Slot_0 only.

Speaker Connections




Monitor Speaker Connections

These take the final audio signal for Left and Right from Slot_0 to the backplane and out to the speakers. These are differential signals and therefore connect to a five-pin audio stereo socket, as connection of the **Negative (-) line to ground will blow the on-board stereo amplifier**, resulting in loss of all audio.

Backplane Headphone Socket


Slot_0 has its own built-in stereo headphone jack socket, and arranged so that when headphones are plugged in the speakers will mute. However, the backplane also has a pin header for the connection of an external headphone jack on a fly lead. This connector is in parallel to the jack on slot_0, therefore for correct detection of connection of headphones in either jack a separate shorting header has been added to the backplane next to the pin header, so as not to mute the speakers.



External Headphone connecting pins


Backlight For Panel

Slot_0 generates the correct voltage through a header select socket for the Backlight of the Panel. This is fed to the backplane so a direct connection from the back plane can be connected. This saves having the cable connected to Slot_0.



Button Bar for Controller


The monitors front button bar with IR receiver is required to connect to slot_0 but again to save having to keep plugging and unplugging the cables the backplane takes the signals. This means unless disassembling the whole monitor these cables are fixed permanently. The monitors main standby button is also connected through this interface.



Interface for Button Bar and Standby Button

5 Volts Main Interconnect


Although there are 4 main tracks for 5Volts to all slots, Slot_0 has extra to help in the reduction of voltage drops across Slot_0, thereby supplying the backplane with the full voltage at currents up to 5 Amps. Slot_0 does not use the 5 volts from the PSU, but derives its own from the 12v supply. All the red lines are 5 Volts.



5 volts connections to backplane

Connections To All Slots

Looking at the Top row, from left to right, here is a description of each connection to all slots on the XRI Backplane.




All slots inter-connections

To the left side of the inter-connects are the main power lines with 12volts supplied through A2, A3, B2 and B3. 5 volts has been supplied through A4, A5, B4 and B5 with additional connections on C2, D2, C17, and D17. Grounds are spread through out the signals on, A1, B1, A6, B6, A11, B11, A16, B16, A21, B21, A26, B26, A31, B31, C1, D1, C7, D7, C10, D10, C18, AND D18.

Component Video

Composite video lines were added for the purpose of cross-connecting the video signals to all slots, to ensure if needed the signal lines were there and could be used.




Component Signals

However, as the circuitry developed it was soon realised that Component did not need to be controlled or display through Slot_0, and only resides on 'Appy's Retro Scalar' using it's Mezze board. This takes Component and converts it to VGA, which then goes on to the backplane. So these 3 lines are now Reserved for Future Use if needed.

Composite 2 and 1

Composite 2 and 1 each uses 3 signal lines each, one for composite video, and 2 for stereo audio left and right. Although on the XRI backplane these are labelled 1 and 2, they are actually mapped to AV3 and AV4 on the Panel Controller with Slot_0 having its own Composite signals for AV1 and AV2.




S-Video

S-Video is similar to Component Video, in that, signal tracks were assigned for it if needed, but with the improved development of the 'scaler' mezze board, S-Video is now handled on that board, and then is directly connected through HDMI to Slot_0 to display on the panel. Therefore these 2 signal lines are reserved for future use.

VGA Video signals and Control

VGA is very important and an integral part of the monitor and thus a large part of the XRI protocol with its own Colour signals, Sync lines, Audio, and Switch control signals.



The VGA signals of the XRI Protocol

Colour

These are the Analogue colour signals for the VGA signal, carrying the red green and blue information on A22, B22 A23, B23, A24 and B24 respectively with each signal on both the bottom A and top B pins. These are then used by Slot_0 to display the information.

SYNCS

VGA protocol only uses H-Sync (horizontal) and V-Sync (vertical) sync pulses to derive its screen resolution and sync the image to that. These are on A27, B27, A28 and B28 respectively. There is then a future reserved line on A29 and B29 before the C-Sync (Combined sync). The C-sync line is just in case a special type pod is used which outputs c-sync. This will be separated into H and V syncs for the VGA to display.

Audio

The two lines are for carrying single ended left and right audio, to accompany the VGA image data.


VGA Control

These 4 signals are used to select which slot takes priority for displaying its VGA information and connecting it to the backplane. Note: each slot can have up to 2 VGA channels, so again, selecting which VGA on that slot is to be connected to the VGA bus on the backplane.

VD_CTRL-0 and VD_CTRL-1 signals control the VGA channel on each slot pod, with VD_CTRL-2 and VD_CTRL-3 determining which Slot to allow its VGA information on to the backplane.

VD_CTRL-2 and VD_CTRL-3

As mentioned previously the two control signals determine which slot has the VGA signals connected to the VGA bus on the backplane.




There is a cross-over between VD_CTRL-2 and VD_CTRL-3, this is to save on extra decoding that would be required on the POD. This way the POD just needs to use the 4th Line for the VGA switch. If VD_CTRL-2 is Selected (Low) then C/D 4th Line on Slot 1 is Low therefore selecting it, where as if VD_CTRL-3 is Selected (Low) then C/D 4th Line on Slot 2 is Low therefore selecting it.

This determines which slot is selected but using the same line on the POD, allowing it to be plugged in either slot.

If slot_0 sets VD_CTRL-2 and VD_CTRL-3 both to (High) so neither is selected, then 'Appy's Retro Scalar' will recognise this, and connect its RF Mezz board to the VGA bus, but this is a SPECIAL CASE, and not to be implemented by any other pod.


IR_IN

The XRI protocol has a signal line for the interconnection of the Infra-Red Signals produced by the IR receiver on Slot_0. This allows pods in any slot to decode the signal and use button presses on the main panel remote control on their own pod.



D3, D5 and D7

These 3 signal lines are used by '*Appy's Retro Scaler*' and the on-board Scaler Control Node. This provides input from a rotary encoder to connect direct to the backplane. To interact through a menu system displayed on a OLED display to select setting for the Scaler Control.






I2C_SDA and SCL


These 2 lines are I²C (pronounced "I squared C") allowing control signals onto the backplane. At present the only 'Master I2C' controller is on the scaler board through the scaler controller. These signals feed and control the displayed data on the OLED, which interacts with the Rotary Encoder.

Monitor POD Design

Shown Below is the overall dimension of the POD PCB's, these need to be accurate, so as to not only fit into the Slots, but to make a good sound connection with the XRI backplane.



Also on the POD PCB, on each side (far left / far right), and top and bottom layer, there is an exposed tinted copper bar for grounding purposes.




Also, on the Left and Right of the PCB, there is a 3.15mm exclusion zone for components, this area should be clear, for the PODs to slide in easily in to the rear of the monitor using the guidance rails built in.

There will be a link later to allow you to download these PCBs as a template for use in KiCad 7 +

Mounting Hole to Fix to Monitor Rear POD Plate.

To mount the POD to the monitor, rear plates, which all PODs are mounted on, allow easy plugging and unplugging from the Backplane, but also fixings and holes for rear connectivity. You can add as many mounting holes as you may



require and also, if implementing a Mezz board to increase rear connector space, holes to fix the Mezz to the POD. But we recommend a minimum and standard positioning of 6 Mount holes.



POD Power From Backplane

As standard, all our PODs take 5V Dc and 12V Dc from the backplane, this then powers the POD by an on/off switch at the rear of the slot. This allows each POD to be individually switched on or off, when not needed. Remember the Standby button on front of monitor only puts Slot_0 in to sleep, but any POD with Power Switched on, will still be powered.

These power switches should be in the same position on each POD, for neatness and easy locating of the switch which is on the rear of the monitor.



Part info.

E-SWITCH


DPDT ROCKER

p.no. 300DP1J1BLKM6QE

MOUSER - 612-300DP1J1BLKM6QE

Power Indicator LEDs


On our PODs we have LED Power indicators, visible confirmation that the Power Switch is on and power is available. They are placed at the rear left of the board. These are optional, however we use a Red LED for 5V, Yellow for 12V, and Blue for 3V3. So if used, try to follow our colours so as not to be confusing.



VGA Switch to Connect to VGA BUS

If your POD requires connection to the VGA Bus then an Isolating Switch is required. This is so that when the slot selected is *not* the slot your POD is in, it is fully disconnected from the VGA lines, does not conflict, or cause VGA noise.

It is recommended to use a switch similar to the SN74CBT3245APWR, this has 8 isolating switches, allowing R, G, B, 3 x syncs and 2 x Audio to be all switched together in a single IC package.




VD_CTRL-2 is used for the switching, as this will allow the use of the POD in either Slot_1 or Slot_2 sockets.

Any input lines should be tied Low, any output lines not used, leave disconnected.


With just the one switch, this gives you only one VGA channel, which will be switched on, whenever the slot the POD is in is selected, so will display for both Channel 1 and Channel 2.

If you wish to have 2 VGA outputs, one on each channel, then you need either 2 more switches (3 in total) controlled by VD_CTRL-0 and VD_CTRL-1 feeding into the Slot VGA Switch, or just two switches, using an OR gate for each switch control. So (VD_CTRL-0 **or** VD_CTRL-2) for one, and (VD_CTRL-1 **or** VD_CTRL-2) for the other.

On our Template, we just have the one VGA Switch, the main one connecting to the VGA Bus. If more are required, simply duplicate the switch circuit, as needed.



Overall Template POD 3D Look



HDMI out

If your POD is going to have a HDMI out (internally connected), then we strongly recommend its placement to the Right of the Slot-fingers. The backplane does not stretch the full way across to the Right and so there is more space for fitting a HDMI Connector into the Socket.

Chapter 13:

Checkmate Monitor – GBS Control

Written by John Ward / jwflame, March 2025

As supplied with the Appy's Retro Scalar pod in the Checkmate Monitor.

What this is

GBS-Control is alternative firmware for the GBS-8200 series of video converter boards that use the TVIA Trueview 5725/5735 video processing chip.

These converter boards were created because most older consoles and computers output video with a 15kHz horizontal frequency which was intended for use with older monitors and televisions. However modern displays use 31kHz, and the vast majority cannot work with a 15kHz input.

Appy's Retro Scalar is based on the GBS-8200. GBS-Control is installed on a NodeMCU ESP8266 module which plugs in to the Scalar. This module and the GBS-Control firmware on it can be configured over WiFi using a web browser, and that configuration is what changes the behaviour of the Trueview5725 video processor chip. A limited set of options can also be selected using the jog dial and OLED display on the front of the monitor.

Using the Scalar

To use the Scalar, your device must be connected to either the SCART connector using an RGB cable, the Component inputs, or the 9 pin connector.

Select VGA on the monitor using the remote control VGA button. If you do not see the input from the connected device, press the CH+ button until you do.

The Scart input will show SCT in green on the display when selected. RGB in green for the component and 9 pin inputs.

If you can only get an image via SCART when AV3 is selected, then you have a cable wired for composite video, which will not work with the Scalar.

Basic Options – Jog Dial

A limited set of options that can be selected quickly. Rotate the dial to move, press to select.

Resolutions

A selection of output resolutions and 'pass through'. Note that pass through will not work with the majority of inputs as it bypasses the Scalar.

Presets

Factory defined presets for some common input formats.

Preset 1 is for standard SCART RGB, try this before changing anything.

Misc

Reset and Restore Factory Settings.

Current Settings

Shows the currently selected settings.

Advanced Options – WiFi Connection

Using a smartphone, tablet or computer, search for a new WiFi connection.

The network name / SSID is: gbscontrol

Password: qqqqqqqq (q 8 times)

Once connected, use a web browser to go to either:


<http://gbscontrol.local/>

<http://gbscontrol/>

<http://192.168.4.1/>

You may get a warning about the site not supporting a secure connection. This is normal, because it doesn't support secure connections.

For smartphones, it may be helpful to temporarily disable the mobile data / cellular data to ensure it only connects to the WiFi.



Some devices may report 'no internet' for the connection –

this is normal.

However certain devices may then switch to another

previously used connection, which will result in the GBS

connection not working – you will see a red flashing icon

at the top right.

The red icon can also appear if the WiFi signal has been

lost, or the module is not responding.

The interface has 5 tabs along the top edge:




From left to right, these are:

- Output resolution and presets
- Picture controls
- Filters
- Settings
- System

Each of these is described separately on the following pages.

If Developer Mode is on, an additional tab will be shown with developer options.

Output resolution and presets



Resolution

Selects the output resolution – this is what comes out of the Scalar and goes to the Slot 0 board.

It is not the resolution of your console or computer.

15kHz is of no use here, as the Slot 0 controller cannot use this format. Pass Through does not alter the resolution of the video. This will be of limited use with this monitor.

Presets


Blue border is what is currently selected. This image shows one custom preset 'JAGUAR' selected and the default 'Empty' one.

Load button – load the selected preset.

Whatever is selected here will also be automatically loaded at startup.

Save button – save to the selected preset, which will overwrite the current one.

If 'Empty' is selected then a new preset will be created.




On the Save screen you can enter a name for the preset. For an existing preset, changing the name will overwrite the existing preset with the new name.

OK to save.

Cancel to return without saving.

Picture controls



ADC Gain (brightness)

Auto Gain will auto-adjust and is the default. Yellow = on. Grey = off.

The + and - buttons can be used to adjust the brightness manually.

Adjusting manually will switch Auto off. Switching Auto on will erase any manual adjustments.

Picture Control

Move – adjust the position of the image.

Use the 4 arrows to move the image left, up, right or down as required.

Scale – adjust the size of the image.

Use the 4 arrows to increase / decrease the width, and increase / decrease the height as required.

Borders – sets the position of where to crop (cut off) the edge of the image.

Up/Down adjusts at the top and bottom of image. Up to crop more, down to crop less.

Left/Right adjusts at the left and right sides of the image. Right to crop more, left to crop less.

Notes on size and position


In some situations, adjusting these too far can result in strange effects such as the edge of the image tearing, folding or parts being duplicated.

The Slot 0 controller has its own adjustments for size and position which are applied after those here. By default that is set to Auto Adjust, however if you have set them manually it may be necessary to adjust those as well.

The Slot 0 settings are accessed using the remote control – Menu button, Picture menu, VGA Setup.

Note that the VGA Setup option is only available with the input set to VGA.

Filters



These options affect the appearance of the image and are all optional.

For these buttons, yellow is on, grey is off.

Scanlines

Either on or off. Applies horizontal scanlines to the image to simulate a CRT.

Intensity

Step through 6 levels of intensity for the scanlines. This button does not change colour, and only works when Scanlines is on.

Line filter


Applies a filter to the scanlines which softens their appearance.

Peaking / Step Response

These are sharpening filters which can improve the image or make it worse depending on your point of view.

These options can be saved with presets if the 'Custom Slot Filters' setting is on – see the Settings section for details.

Settings



For these options, the button is blue and to the right when on, grey and to the left when off.

Matched Presets

On – defaults to 1280x960 for NTSC sources or 1280x1024 for PAL.

Full Height

Scales the image vertically to fill more of the height. Only works with output resolution 1920x1080 which is a poor choice for this monitor as it's the wrong aspect ratio.

Low Res Use Upscaling

Selects whether scaling should be used for low resolution inputs. This should be left On, as that is the whole point of the scalar.

RGBHV/Component Toggle

Off is the default output mode of RGBHV, which outputs VGA. On is YPbPr output, which will not work with this monitor as it requires VGA.

Output Frame Rate

On sets the output to 60Hz, even with 50Hz inputs. Reboot required to apply this setting. This will result in less smooth video due to the frame rate conversion. Do not use this unless you have a very specific reason for doing so.

ADC calibration

GBS Control calibrates the ADC offsets on startup – the internal settings for the individual red, green and blue signal levels.

This should be left On unless you want to adjust things manually in Developer Mode

Active Frame Time Lock

When enabled, this aligns the input and output timing, which should fix horizontal tearing in the image. When enabled there are two different options, which are selected using Switch Lock Method. These options may cause an unstable image, or no image.

Deinterlace Method

This settings has two toggle selectors, but only one can be active.

Interlaced video is automatically detected, and when it is, there are two options for processing it:

Bob - essentially no deinterlacing. No added lag but there may be some flickering.

Motion Adaptive – This removes flicker, but will add one frame of lag and may result in artefacts in moving details.

To avoid deinterlacing, the input source must be Progressive.

Developer Mode


When On, an additional tab is visible with many options for development purposes including a text console. Some of those options will cause problems if used incorrectly. Developer Mode and its settings are outside the scope of this guide.

Custom Slot Filters

When On, saving/loading a preset will include custom filter settings. This is useful if you want different scanline settings for each preset.

When Off, the filter settings will not be changed when loading presets. Use this if you want the same scanline settings for all presets all the time.

System



Enable OTA

This allows firmware updates over the network connection rather than directly connecting to the module via USB.

This option is not recommended – if you are intending to use different firmware, then you should buy another module, configure that outside of the monitor, and then swap for the module supplied with the monitor.

Do NOT reprogram the module that is supplied with the monitor – if something goes wrong, the Scalar will be inoperable until you buy another module and install the correct firmware on it.

Restart

Reboot the control module. Necessary if changing certain settings such as forcing a 60Hz output frame rate.

Reset Defaults

Resets most things to default.

Backup

Download a backup file containing all settings.

Restore

Upload a previously saved backup file to restore settings.

Wifi Access Point

Access Point – this is enabled by default as this is what you use to access over WiFi. Disabled if the module is connected to another WiFi network.

Wifi STA / Scan Network

Connect the module to a local Wifi network, so you can then access over that network rather than directly.

When selected, a list of available networks will be displayed. Select yours, enter the password for that network and select Connect.

Many thanks to John Ward / jwflame, March 2025

Chapter 14:

CHECKMATE MONITOR RF INPUT & RF REMOTE CONTROL

Selecting the RF input

Make sure the Scalar is switched on using the power switch on the back.

Using the large Checkmate branded remote, press Source, then select VGA from the options displayed.

Now press CH + until you get to the RF input, which should show as black/white noise covering most of the screen.

Connect your computer, console or other device to the RF port on the Scalar.

Now you can use the smaller RF remote control to tune in and adjust various other settings.

Remote Conflicts

Note that there are conflicts between the two remotes, so pressing buttons on the larger Checkmate remote may have undesirable effects on the RF module, such as Mute will select CH4 on the RF module, and adjusting volume UP will switch between the denoise settings.

This is because the RF module is a totally separate device, and was never intended to even be in this monitor, and therefore some conflicts with the IR remote signals is pretty much inevitable. As mentioned in the main monitor manual, the RF module was a free addition with the S-video and it is intended to have a combined remote in the future.

Volume

The RF remote volume buttons only control the sound output from the RF module. In order to hear anything, this needs to be set fairly high, AND at the same time, the main monitor volume must also be set appropriately using the larger Checkmate remote.

If there is no sound or it's very low, suggest using the small RF remote to set the volume to 100 (maximum) and then use the Checkmate remote to adjust to a suitable level.

If the RF or Checkmate volume is low/off, you will not hear anything.

Same applies to the MUTE buttons – if one or both are muted, then you will get no sound.

RF Remote Control Buttons

Some of these buttons are not used, or have functions which are of no real use here, as this was designed to be a television receiver and not for computers and consoles. The useful ones are described below. Others really should not be used, as they may result in settings that create an unusable image. Press at your own risk.

Red (top left)

Power on/off. This just turns off the RF device, nothing else. Suggest NOT using this as it will just lead to confusion with 'no signal' displayed. The RF module defaults to ON when power cycled.

Green (top right)

Sound mute. This ONLY mutes the RF sound. Press again to unmute.

When pressed the volume bar is shown on screen – white is sound on, green is sound off.

Pressing V+ will also unmute, however V- does NOT unmute but will reduce the volume level for when it's unmuted.

Numbers 1234567890

These select the tuning presets. Numbers are arbitrary and just relate to what is stored in that preset.

For the original use as a TV, these would be your different TV channels. For consoles and the like, you will probably only need one, so it's 1.

Theoretically possible to store more than one if you have devices which output the RF signal on different frequencies.

Centre Buttons

P+ / P- will step up/down through the presets if you have more than one, an alternative to using the numbers.

V- / V+ is the volume, as mentioned earlier suggest that this is set to 100 and left there.

Menu opens the menu where many things can be adjusted, see later for details.

Preview

This splits the screen into 9 areas, and frame grabs an image at approximately 2 second intervals for each of those 9 areas, then repeats. Press again to exit. A kind of video thumbnail generator.

This feature can be changed to 4 or 16 images in the menu.

Denoise

Cycles between four denoise settings – High, Middle, Low, Off. These make various adjustments to the picture, choose one that looks best for your device. This can also be changed in the menu.

Other Buttons

Suggest NOT using any of the other buttons, as they can result in some very strange and unwanted results, some of which will make the image either unusable or not what you want, and it may not be obvious or easy to undo these. They are basically shortcuts for some of the settings available in the menu.

Menu Options and Usage

Press Menu to display the menu. There are five sections:

Picture – TV – Audio – Sys Settings – Time

To move between these use the left/right buttons (V-/V+)

To enter a section and select an option, use up/down buttons (P+/P-). The item is highlighted and a finger icon shows to the right.

To exit a section, press Menu, you can then use left/right to move to a different one.

Press Menu again to exit completely or just wait a few seconds at any point.

Timeout is only a few seconds from any selection, and it doesn't appear to be adjustable.

With any item highlighted and the finger icon showing:

If the selection has numbers or other values, use the left/right buttons (V-/V+) to change the value.

If it has a small square icon, press Right (V+) to access a submenu which will have further options that can be changed.

All changes are implemented immediately, there is no save or confirm option.

The easy and obvious settings

Picture and Audio do exactly what you would expect, and the Time section really isn't of any use here.

Picture

Brightness, Contrast, Saturation, Hue have values from 0-100. Default is 50.

Color temperature is Normal – Warm – Cold. Default is Normal.

Picture Mode is Bright – Soft – Normal – User. These are just preset options for the other values.

If any of the other settings are changed, Picture Mode automatically switches to User.

Adjust these as desired for your particular device.

Audio

Volume and Balance are values from 0-100. 0 is left, 100 right. Default is 50.

As previously, suggest setting Volume to 100 and leaving it there.

Stereo can be On or Off. Unclear what this is supposed to do, as RF audio is generally mono anyway.

Time

This can be used to set various auto on/off features and other reminders on a calender and clock.

This will not be of any use in this application. May have been of value if this was a television.

The TV tuning department

TV

This is the tuning menu, where you will need to tune in to the frequency and other settings appropriate for your device.

Auto Scan

This only has one option – Normal Scan – which will start a scan of the entire frequency range and store anything it finds into the presets. This would have been useful if this was a television receiving many channels, but it's not of much use with a console or computer as there will only be one to find. It does work, but will take a long time to complete. It will also continue scanning even after it's found your device which is a waste of time, but that's just the nature of scanning the entire range of frequencies.

Frequency is displayed as the scan progresses, and the number above the frequency is the preset it will store the next channel into. Starts at 1, when this changes to 2 it has stored the preset for your device.

Note that Auto Scan will erase all existing presets.

Manual Scan

Channel – the preset number where these settings will be stored.

Band – VHF Low, VHF High, UHF. Which this is depends on your device. For the UK, it's UHF.

Search – Initiates a scan of the selected band

Fine – Fine tuning, use left/right to adjust the frequency for the best image.

Frequency – indicates the current frequency while the scan is in progress. For most UK home computers and consoles it should be found at 591.25MHz which is UHF 36.

To scan and tune to a single channel, select the appropriate Band, then select Search. Frequency will count up until it finds something. Hopefully that something is your console or computer. If not, you can Scan again.

After it's found something you can use the Fine option to improve the image if necessary.

You can store more presets if desired by repeating the above steps on a different channel (preset) with a different device connected to the RF input.

Sound Sys

This is where you select the audio subcarrier. This will be determined by the device you are using.

If this is wrong, you will either get no sound, or just a lot of noise. Some of these may affect the picture as well. Generally it will be obvious if this is wrong.

Options are I, BG, Dk, M. For the UK, it's I.

CH Exchange 1 / CH Exchange 2 / Exchange Confirm

These are used to swap channel presets, such as moving 1 to 4 and 4 to 1 so they can be rearranged into a desired sequence. Not likely to be of much use here, intended for if this was used as a TV with many different channel presets stored.

Here be Dragons

Sys Settings

There are a lot of things that can be adjusted here, some of which will result in an unusable image.

OSD Settings

Options for the on screen display (the menus).

Language – English or the other choice. DO NOT change this unless you want a pile of problems.

Bright – Adjusts brightness of the OSD. Options are Gloom, Bright, Normal

Background – Changes the OSD colours. There are 5 options plus Mix which is partly transparent.

Display Mode

This is an area where wrong settings will cause the image to be incorrect or not there at all.

Signal Source – TV or AV. Doesn't appear to make any difference. TV is default.

Color System – Pal, Ntsc, Pal N, Pal M, Secam, auto.

Select whatever is appropriate for your device, which is generally determined by the country it was intended to be used in. Auto may select the correct option for you, but it may be necessary or desirable to pick a manual option with some devices.

PAL is for the UK, most of Europe, Australia, some parts of Africa.

NTSC for North America, some parts of South America, Japan

SECAM for France, Russia, some parts of Africa

Pal N and M are for a few countries in South America only.

The next two options WILL cause the screen image to be altered in ways you probably do not want.

Tamper with these at your own risk.

Monitor Type – 4:3, 16:10, 16:9. Changing this will also change the Display Ratio at the same time. 4:3 is the default setting.

Display Ratio – Default is 1280x1024 60Hz.

The others are:

4:3	16:9	16:10
800x600 60Hz	1366x768 60Hz	1440x900 60Hz
800x600 50Hz	1600x900 60Hz	1680x1050 60Hz
1024x768 60Hz	1920x1080 60Hz	1920x1200 60Hz
1024x768 75Hz		
1280x1024 60Hz		
1280x1024 50Hz		
1600x1200 60Hz		

Pop Mode

Selects the screen position for a picture-in-picture feature which is neither useful or possible to use with only a single channel preset.

Browse Mode

This is how many screen images are shown when the Preview button is pressed. 4, 9 or 16.

Advance Settings

Denoise – options are High, Middle, Low, Off. Same as pressing the Denoise button.

Ble – On or Off. Unclear what this does if anything.

GAMMA has Off – LCD - CRT – Normal. Adjusts the gamma curve of the image, may be useful in some circumstances.

Wide Screen – Normal, 4:3, 16:9. Changing this may result in a squashed or stretched image.

Blue Background

On or Off

Factory Mode

Selecting this will reset the device to factory defaults and erase all tuning info.

WARNING – THERE IS NO CONFIRMATION HERE, it's press once and you are reset.

Version

The firmware version is displayed at the bottom of this menu. For info only, there is nothing to select or change here.

It's all gone horribly wrong and the factory reset option is needed

The RF module can be reset to factory default which also erases all tuning presets.

If you have somehow selected the language which is not English and then immediately regretted it, then your options are:

Factory reset

Menu

Right – Right – Right

Down – Down – Down – Down – Down

Right

To just change the language option

Menu

Right – Right – Right

Down

Right – Right


Many thanks to John Ward / jwflame. Version 1, January 2025.

Chapter 15:

Installing MiSTer into the MiSTer fitting kit.


Start with the empty tray as shown. Mister fits on the right side, power board on the left. This is for a black monitor, it's identical for the white versions.

These instructions assume you have some knowledge of the MiSTer such as knowing what one is, and you have put one together before. If not then there are plenty of guides available elsewhere.




Place the USB hub onto the four raised bosses and secure using brass standoffs, one in each corner. They can be a little tight sometimes !

Note power connector is to the LEFT side, facing the location of the power board.




You can use thin nose pliers to secure the rear standoffs. Hand tight only, do not overtighten.




Place the small USB connector board onto the USB hub (rear right of photo). Make sure all 4 pins are aligned.




Place the DE10 nano above the USB hub, and slide across to connect to the USB board on the right side. This photo shows RAM, heatsink and real time clock module already installed on the DE10 nano.




View of USB hub connection (right side of boards)




Use four brass standoffs to secure the DE10 nano to the USB hub.




View of the left side of the boards – note both power connectors are on the same side and one is directly above the other.




If needed, Place the IO board on top of the DE10 and ensure all pins are properly aligned before pressing together. This is a digital IO board. Other types of IO board are available but all connect in the same way.




Secure the IO board using four screws.



Power board installation – this board and the screws are included in the fitting kit.




Place the power PCB onto the four raised bosses with the power switch through the hole in the backplate.



Secure with four screws.

The power switch on this board can be used to switch the Mister on and off from outside the monitor, rather than using the small power switch on the IO board.




Connecting Cables

Three cables are required, and these should be included with the fitting kit.

HDMI – one end connects to the HDMI socket on the DE10 nano, the other inside the monitor.

USB power supply – The small white connector plugs into the power board. The other end has a USB connector which connects inside the monitor.

Power – There should be a Y power cable included. One end plugs into the power board, the other two plug into the USB hub and the DE10 nano. Note it is NOT necessary to connect any power to the IO board on top, as this gets its power from the DE10 nano, and the IO board power switch is not used here as it's inside the monitor.



Installing in the monitor


IMPORTANT – Disconnect the monitor power cable before removing or installing pods

If you have the Scalar or anything else installed, it must be removed to access the connectors for the MiSTer. If you have the Svideo/RF board as well, there will be a HDMI cable attached which you will need to unplug before fully removing the Scalar board.

The USB power plug connects to the backplane socket marked USB_PWR

The HDMI cable connects to one of the internal HDMI ports on the Slot 0 board. Any free HDMI socket can be used.


Be sure to route cables to the right side of the cabinet, so that they are not in the way of the board edge connectors.



Secure the MiSTer pod into the monitor, make sure that cables are not trapped or damaged when doing this.

This shows the MiSTer in the upper slot (Slot 2), it can be installed in the centre position if desired.

Spare holes in the backplate are for VGA and VGA audio (left side) using extension cables – this is only applicable to analog IO boards. Right side is for an Ethernet cable, which extends the socket on the DE10 nano to the backplate. Alternatively a WiFi module can be plugged in to one of the USB sockets either internal or external.



You can now test the MiSTer by connecting power, switching the MiSTer and Slot 0 pods on, and selecting the appropriate HDMI input. If unsure which one, just press the HDMI button on the remote several times until you get the Mister display.

Once configured correctly and no further access is required, reinstall the Scalar if you have one.

The HDMI cable shown loose in this photo plugs into the Scalar Svideo output.



Completed assembly with the Scalar in Slot 1 and MiSTer in Slot 2.











Many thanks to John Ward / jwflame. Version 1, January 2025.





Chapter 16:

Photo gallery of my install











Meet Appy

A profile of our Chief Engineer



We wouldn't be able to do what we do at all without the almost magical electronic skills of our chief engineer and designer Paul, who always goes by his nickname "Appy". Appy's had a difficult journey to get here and we thought we'd share his story because personally we find it inspiring.

It's not easy growing up with mental health problems; we all have them in one form or another from time to time and we all deal with them in our own way. In Appy's case for years he was undiagnosed but was living with what used to be called Borderline Personality Disorder (or BPD) but which was recently renamed officially as Emotionally Unstable Personality Disorder (or EUPD.) This disorder means you have difficulties with how you think and feel about yourself and other people, and these difficulties make it hard to cope day to day. Experiences of BPD are different for different people, but commonly you may experience emotions that are very intense, overwhelming or changeable. Obviously this does not make for an easy life. People suffering from BPD

unintentionally alienate those around them, even those they love, and this creates a lot of suffering and heartbreak.

As Appy says "I've been through a few courses of dialectic behavioural therapy (DBT). I've done bits of CBT (cognitive behavioural therapy) but they're just short treatments. DBT is a year-long program. Through that I'm trying to learn not to react to emotions so strongly. So if someone upsets me instead of going off the deep end, I'll pull back a bit further. It's ruined many a party. The whole party would end up erupting because of me."

Appy is quite open about his mental health status, and talks about it quite freely about how he copes and tries to live a mostly happy and fulfilled life doing what he loves the most. Building stuff.

From Pubs to Subs

In his youth any time he was annoyed by something he became uncontrollably angry, and everything people tried to do to help seemed to make it worse. Some sufferers describe BPD as being like the emotional equivalent of a burn victim, where everything people say and do seems very intense and painful and they have no protection against it.

If Appy was angry he was super angry, if he was sad or depressed it was overwhelming and disabling. These feelings would persist for days or change abruptly to another deeply felt and hard to tolerate emotion. In the end the only way he could get through the day without blowing his life up every five minutes was to drink. Obviously for a variety of obvious reasons this is not an ideal solution, but for him it works in a way that medication doesn't. He can't drive ever obviously, but in every other aspect of his life he can cope and concentrate and live productively.

"My way is just to drink through it. But when I say I'm an alcoholic, I'm not a (I hate this phrase but my psychiatrist always used it) an 'under the bridge' alcoholic. You know, what people think of as sitting under a bridge with a bottle of vodka. I don't drink to get drunk. I just drink from when I get up and it keeps me steady all day. In fact I can't function without it. If you've seen some of the soldering I have to do, I have to have at least three cans before I can address it as I am. We're talking chips with 160 pins!"

Mental health problems and high intelligence often go hand in hand, and Appy is super smart. From quite modest working class beginnings he was always

eager to learn about mechanical and electronic devices, taking stuff apart and putting it back together again. But he was in his own words not in the sort of family that expected to move into higher education, so he had to be self taught and he learned through experimentation. That said he now has two degrees that he earned through the Open University in Electronics and Computer Engineering so he's done the book work and got the gongs to prove it.

"I came from not an educated family, you know? My dad worked for the council digging holes in the roads and pavement. My three older brothers hardly went to school, and skived off most of the time. I was the only one to go to a different final school. The school my brothers went to was one of the worst schools in the area. Everything I know was self taught or already built in.

"Back then I was constantly taking VHS recorders apart and satellite decoders, and sometimes my mates would say could I mod their games console. Like the one mod I used to do was for the Sega Mega Drive to make it so you could switch between NTSC and PAL, things like that.

"I never had a games console. 1) I wasn't really interested in games and 2) I needed money to buy my computer."

"When the Amiga 1200 came out I just had to have one. I really loved the 1200. And because I wasn't really into playing games, it didn't bother me that half the games didn't work on it. I was in it for the music. I loved the extra chip RAM so I could have bigger samples. The amount of colours was massively increased. It's just great. And AMOS worked even better on the 1200."

But being smart means you have PROJECTS and he had to fund his electronics exploits and computing and music. So he started off his working life, initially in pubs, rising quickly from the role of glass and bottle boy to publican. But although access to alcohol to smooth his emotional rollercoaster was useful, his mind was unsatisfied with the work and this frustration was amplified by his condition. He had to get out and do something.

He decided to stop pulling pints and serving food and be what he really wanted to be, and that was an engineer. He joined the Royal Navy initially for a 4 year apprenticeship as a weapons engineer including mechanics, welding, turning and metalwork.

A Life on the Ocean Waves

Fortunately for Appy there was a culture of drinking in the Navy. In the olden days of sailing ships it was a rum ration, but in the modern Navy every "mess" (an area where personnel socialise and eat) has a beer fridge. The problem was that these beverages were doled out at a certain time of the evening and were locked at other times. That is, it was a problem until he'd discovered that one of the cabinets from his computer room had the same keys as the beer fridge.

After 5 years of learning and service he was eventually discharged from the Navy during a bout of mental health problems as "temperamentally unsuitable". He jokes it was *"because I didn't want to be on ships. I wanted to be shoreside where I could go to the pub every day."* So from his discharge he went back to the shore base, HMS Collingwood. While apparently temperamentally unsuitable for work aboard ship, clearly the Navy didn't want to lose his talents because once installed shoreside he got a bump in rank from Leading Hand to Lieutenant and a post as an instructing officer, teaching there for an additional 2 years.

"I ended up teaching the Royal Navy personnel, but civilian personnel too because we were teaching apprentices for companies like BAE Systems, Kinetica and all the other ones. So I was teaching them and on final presentation day their bosses came in and I got chatting with one of the BAE bosses. Next thing I know he took me up, I got a job at BAE working on torpedos and testing them."

Working at BAE was really good for Appy, and the evidence is in the fact he was working there for 15 years. A part of the success of the job was due to his co-workers who understood and supported his mental health issues. As time wore on however many of these supportive co-workers began retiring and there were redundancies too. At the same time Appy was going through some personal problems too, with a stressful and difficult separation from the mother of his children. So after 15 happy years at BAE he retired due to ill health.

"My mental health just wouldn't cope with the working environment. Lots of people I relied on for support left. HR and the company doctor said 'we can't cope with the amount of time off you have'. Because by that point I was having a year off on full pay, and then working a year, then having another year off on full pay. I did that for about the last 5-6 years. They wouldn't give me redundancy, so I said well, I'll go for a medical retirement. Straight away I

got a letter back saying no. So I appealed it and I had to go through some tribunals etc. Then they came back 'We're retiring you. Here's a big pension and here's a big lump sum.'

This of course worked out well for us when we met him because although our ideas are, of course, *amazing* and we are geniuses at bolting stuff together, Appy adds a bespoke neatening up of our ideas using his unique set of technical skills.

All Round Engineer

Technically speaking Appy brings a lot to the table. He has two degrees and a masters in engineering. He is an electronic engineer. He has CNC machines, milling machines, a pillar drill and a metal bending machine. He's experienced in welding, turning and all types of metal work. The reason for this all round expertise is partly to do with life as an engineer on a ship.

"When I did my apprenticeship in the Royal Navy, we did everything hands on. Because the way they see it is when you're on a ship, if something breaks and there isn't a spare in stock on the ship, you have to make one out of raw materials."

Appy is also qualified, and everything he designs for us is military specification.

"I've been doing electronics since I was 12 and I'm 48 now so that's 36 years. But a lot of experience as well and not all in one area. From Navy engineering, teaching engineering then designing weapons and test systems for those weapons. I'm also a bit of a perfectionist and when it comes to engineering and I'm a professional. It has to be a professional product."

"Military Spec is just a little bit more hardy, like the temperature coefficients, the temperatures it has to operate over are wider. You also have to take into consideration IP or Ingress Protection, so how much water could it withstand before it would leak or break or how big a finger can you put into it, you know, for safety. There's also environmental conditions, like you don't want condensation, so you might have to put heaters in to stop it condensing when it's not on. You've got to do drop testing as well where you literally drop it and hope it still works."

IP protection is pretty standard these days but Appy's Navy training has also made him an expert in areas which are much more important in consumer electronics now than they used to be, like EMI or electromagnetic interference.

"One aspect is how much information does it radiate out. The other is how much of a lightning bolt strike nearby could it handle without being damaged. With the old CRTs if you left a door open on a ship, another ship that was passing you would be able to pick up the radiation from the CRTs and display them. You don't want noise interfering with other systems, but you certainly don't want the noise being picked up by the enemy, who could then decode them and learn your secrets. It's easy to pick up someone's noise and regenerate it back into what it was."

In this modern age of cybercrime obviously that sort of awareness is crucial to creating safe and secure products.

An Appy Future

When we met Appy we were fascinated by his skills, and his story, and knew he could bring something amazing to the table. We accept and support his mental health issues and are in awe of his ability to do what he does and live a relatively steady and happy life. And he's really happy working with us too, which is great.

"We get on, in personalities as well. Obviously my personality can clash a lot, well it does clash with a lot of people. Especially non-engineers. But then as an engineer I can't even spell it. (Bit of an engineer joke from Uni)"

"It's great when I get a chance to go to events because I get on with the people so great. My mental health issues just aren't there when I'm around the retro community people. We're all just accepted as we are so that keeps me really calm and never a problem. Also some of them have problems with their mental wellbeing too, but that's life isn't it?"

Appy makes everything we do better, more professional and more tough. We're so glad we met him and that we can enable him to do what makes Appy happy.

Chapter 18:

A thank you message to all involved in this project

When I set out on this project I did it alone, but I knew that I needed people with expertise in the many areas that I am lacking.

Over the time of this project development some are no longer involved, but the help they gave cemented the road map I had envisioned and made me realise I could complete this and far exceed the original scope in making it a far more user friendly and better quality design overall. This meant heavy custom design work rather than the original off the shelf nature that I felt was needed due to lack of engineering talent I had available in myself.

Firstly I want to thank Byron, whilst he thinks his contribution was small, the truth is that his input gave me access to utilising the original GBS 8200 and the GBS-Control Node system and having RGB Scart. Thank you Byron.

Throughout this project Kickstarter preparation I had graphics support from Paul Kitching with his usual amazing 3D renders of the design. Samuel Hurl created the Kickstarter video which wowed people and Phil South helped enormously by making my words make sense as he will do with this manual.

Peter Leigh (Nostalgia Nerd) was instrumental in getting the Kickstarter project over the line and without his video we may not have reached the goal. It is important to know we paid him nothing, he even bought the coffees, but his enthusiasm was the key factor to his support.

I have to thank all of the companies supporting me during this process mostly in China but one person I will highlight is Sara Tian who not only is my support at the tooling company for the chassis but also volunteered to be my translator in China when visiting lots of companies.

I also want to thank my wife who helped me sort out my accounts with this project and of course her support.


However, one person stands out and to who I am indebted too because his great engineering work transformed my project from a flexible and modular system but with off the shelf components type of project to a custom hardware and more flexible system including the XRI backplane instead of loads of cables internally.

He also allowed me to replace the original GBS8200 which was flawed and do a custom 4 layer board with the main TrueView chip with great VGA output to the back plane and multiple retro inputs plus an expansion to enable more

from third parties. I am of course referring to 'Appy' who is the engineer I'd always needed throughout my career back in the day to make my ideas real.

Finally, my Kickstarter backers to whom I owe the enabling of this project, thank you.

Steve Jones



Chapter 19:

My Kickstarter Backers

Without these people on the following pages you would not be reading these words because this product would not exist.

Please note I am using their Kickstarter names only, so apologies to those who did not put their full name but I assume you did this so as to remain private and I respect that.

Steve

3D-vice Visual Design	Andrew Guzman	Benjamin Kleiner	Christian Albertsen
A. Smith	Andrew H.	Benjamin Nolan	Christian Dannie Storgaard
Abdulbaki Uzun	Andrew Hagedwood	Benoit Couamin	Christian David Hanks
Abe Jun	Andrew Henriquez	Benson Ang Rui Xuan	Christian Gräfe
Ada Worcester	Andrew Hey	Bernhard Arbeiter	Christian Holzapfel
Adam	Andrew Kerr-Thompson	Bernhard Lukas	Christian Sauer
Adam R	Andrew Lee	Bert Jahn	Christoffer Gurell
adam820	Andrew Lytle	Bhadra Walker	Christoph Fockenberg
Adrian	Andrew McKillen	Bieno Sesentaycuatro	Christophe Chevalier
Adrian Hanington	Andrew Mellor	Bill Loguidice	Christopher Baker
Adrian Klink	Andrew Poh	Bill Parnell	Christopher Cook
Ahmed Hassan Jassim Al-Thani	Andrew Ruth	Bill Soreth	Christopher Cowles
Akei	Andrew Searle	BillyHGLGR	Christopher K. Sokolov
Akimasa Yamada	Andrew Seeger	BJ	Christopher Rivett
Al Stremming	Andrew Sellors	Bjoern Baranski	Christopher Stewart
Alan	Andrii Romaniuk	bjsallee	Christopher Stokes
Alan Barrie	Andy	Bluey	Christopher White
Alan Field	Andy Hayes	Bob Illig	Clinton Bobrowski
Alan Gray	Andy Libeck	bobeff	Clive
ALAN HARD	Andy Nightingale	boidret	Clockwork Jam
Alasdair Simpson	Andy Palmer	Boo Gafford	CmpingSmktrd48
Alec Konynenburg	Andy Raisovich	Brandon Breymeier	Cody Wilson
Aleksandar Vujovic	Andy Rumer	Brandon Michel	Coestar
Aleksandr Nikitin	andyhilton	Brent Silk	Colin Reed
Aleš Jelínek	anonymous	Brett Lamb	Colin Stone
Alessandro Pavan	Anthony Cafarelli	Brian	Collin Pieper
Alex Balcanquall	Anthony Cullerton	Brian Archer	Colm McCallion
Alex Jeannopoulos	Anthony Davison	Brian Armstrong	Conan Thomas
Alex Kain	Anthony Jarvis	Brian Condron	Conner Coates
Alex Lozano	Anthony Orr	Brian Gosney	Connor Elam
Alex Mirkovic	Anthony Ray Billings	Brian Holloway	Copec
Alex Reventlow	Anthony Witham	Brian Kavanagh	Craig Burgess
Alex Sole	Antonio	Brian Last	Craig C
Alexander Facchini	Antony Oldham [Founder]	Brian Lawson	Craig Cargill
Alexander Heidenreich	Antony T Curtis	Brian Morrison	Craig Ferguson
Alexander Holland	Archaon88	Brian Ng	Craig Marshburn
Alexander Obermann	Arcticfox	Brian P. Mueller	Craig Medland
Alexander Roebers	arioncn	Brian Watson	Craig Richardson
Alexis Chacon	Arjan Vos	Brielle Harrison	Cris Matthews
Alfred John Pavlik III	Arkadiusz Bronowicki	Bruno Fonseca	Cristian Prieto
Ali Alsawaf	Arkadiusz Kwaśny	Bryan Sawler	Curtis Michels
Ali Ben-Mussa	Armin Diethelm	Buff Bot	D G Rioux
Alisha Manuela Stutz	Arne	Burke Cates	Dag-Erling Smørgrav
Allan Cairns	Arnt Todnem	Calvin Morrow	Dale Fry Kirkwood
Allan Versaevel	Arokh	Cam Urquhart	Damien Cooley
Allen Huffman	Art d'Os	Cameron	Dan
Allen Ramirez	Arto Vainiolehto	Carl Macmillan	Dan Foster
Amazing Games Studio	Arttu Kärpinlehto	Carsten Elton Sørensen	Dan Kanemitsu
Amos Defamos	Arturo Arreseigor	Casey A.	Dan Sanderson
Amram Carciente	Arun Tahlan	Chad Abbs	Dan Spitzley
Anastasios Birmotsoukis	Ashley Dawson	Chad Whitely	Daniel
Anders Lith	Åsmund T. Johansen	Chance Davis	Daniel Cameron
Anders Nielsen	Asobi.tech	Charles Barker	Daniel Hicks
Anders Öster	AU	Charles Paek	Daniel Hogberg
Anders Ström	Austin	Charles Swenor	Daniel Jewell
Anders Svensson	Axion	Charter McCloskey	Daniel McQuiston
Andreas Dziesiaty	B Hasberg	Chips98	Daniel Rolfe
Andreas Feese	B. van Hamersveld	Chris Becker	Daniel Roses
Andreas M. Schmidt	barney	Chris Branch	Daniel Stafberg
Andreas Micklei	Barry Quine	Chris Doig	Daniel Stephens
Andreas Schneider	Bart Jeepsz	Chris Ellerbeck	Daniel Whitehead
Andreas Strid	Bart van den Akker	Chris forrester	Daniel Williams
andrej kastelic	Bastian Zühlke	Chris Hooper	Danielle Hallett
Andres EL Villano	Béla Benedek	Chris Koch	dannyboy_77
Andrew Ajello	Ben	Chris Morris	Darkk the Dragon
Andrew broadhurst	Ben	Chris Newton	Darrell Westbury
Andrew Brown	Ben Anderson	Chris Odom	Darren Hawkins
andrew cunningham	Ben Gorman	Chris Rowe	Darren Johnstone
	Ben Gray	Chris Wallace	Darren Rees

Andrew Dowden	Ben Longden	Chris Wilkins	darren torrington
Andrew Dudgeon	Ben Madore	Chris.k	Dave
Andrew Fawcett	Ben Wiseman	chrisbfan	Dave Bauchan
Andrew Gilchrist	benjamin bruheim	chrisbrentano	Dave Carroll
Andrew Gillen	Benjamin C. Wiley Sittler	Christer Lindgren	Dave Chase
Dave Nolan	E Roney	George Warren	James Alston
David	ecaredit	Gergely V	James Balderson
David	Eduardo Teixeira	Gibbon	James Bamford
David	Edward Dischley	Gideon Jones-Davies	James Bradley
David Allen	Edward Giertuga	Glenn Garrett	James Brown
David Arbesman	Edward Gower	gorish	James Challinor
David Bailey	Edwin Williams	Graeme Burdis	James Gorman
David Baisley	Efraim Juntunen	Graham Archer	James Kachel
David Bridgfoot	Einar Jørgen Haraldseid	Graham Crump	James Moorcroft
David Dittmar	Eirik Øverby	Graham Lacey	James Podesta
David Douglas	Eiríkr Ásheim	Graham Wood	James Rigby
David Fumberger	Eivind Rannem Bøhler	Grant Forrest	James Rizzo
David Gosling	elb98rm	Grant Shipley	James Sutcliffe
David Guida	elfkerben	Gray Defender	James Tinmouth
David Hawkins	Elliot	Greg Jones	James Veitch
David Johnson	Emily Allom	Greg MacKinnon	James Wahls
David Meadowcroft	Emma Anderson	Greg Mitchell	James White
David mears	Emmanuel Leroux Sanders	Greg Moody	Jamie Hoyle
David Moore	Emmett Baker	Greg Soravilla	Jan
David Murray	endicott lovell	Gregory Tylka	Jan Godwod
David Perry	Eric Drexler	Grzegorz Krzystek	Jan-Erik Sundh
David Ramsey	Eric Lind	guetech	Jani Halinen
David Romero Pérez	Eric Michael Strawser	Guillaume Tremblay	Jani Lammi
David Rosa	Erich Sütterlin	Beaumont	Janne Heikkinen
david sives-rutherford	Erik	Gunnar Wretling	Janne Sirén
David Wadsworth	Erik Grissom	Gurce Isikyildiz	Jared Micks
David Warner	Ethan	hairyone	Jas Lambert
David Watson	Fai van Dooren	Håkan Jonsson	Jasen Rogers
David Wright	Falconer	Haley Skaggs	Jason Campbell
davidmt	Fantomen	Halstead York	Jason Fergus
Dean	Fasih Rehman	Hannes Walder	Jason Galarneau
Denis Comtesse	Federelli	Hans Mueller	Jason Glose
Dennis	Felipe	Hans-Georg Eßer	Jason Goy
Dennis	Felix	Hasan Coskun	Jason Herrick
Dennis Pauler	Ferdinand Vykoukal	Heine Jeppesen	Jason Kenney
Dennis Sievers	Fergal Byrne	Helge Alsvik	Jason Schofield
Derek Brown	Filippo Borselli	Henri Sundelin	Jason Strothman
Derek Chandler	Filupe	Henric Wallqvist	Jason Strudwick
Derek Morrison	Finn Arild Thordarson	Henso	Jason Taylor
Derek Sheppler	Finn Johansen	HovellingHermit	Jason Woodhouse
Derrik	FLEABttn	HP van Braam - Xenon	Javier Rosa
Detlef Grohs	Florian Hallberg	Special Forces	Jay B
Devin Rojas	FlukeRogi	Iain Brighton	Jay Jackson
devoughn accooe	fmatzke	Iain Mason	Jean-Baptiste BOLCATO
Dimitris Giannakis	Forrest Greenwood	Ian Bremner	Jean-Christophe Culot
Dino Terzic	framerateuk	Ian Cross	Jeff
DJ Mangus	Francesco Tagliaferri	Ian Law	Jeff Boschee
djklfjds	Francisco	Ian Richardson	Jeff Cooper
Dmytro Hrybenko	François Andriot	Ian Wright	Jeff Robison
Dominik Reichardt	Frank Caputo	Igor Ianov	Jennifer Glauche
Dominik Schläpfer	Frank Durban	Igor Stoimenovski	Jenovi
Don Rouse	Frank Eersels	Ilia	Jens Bagh
Donald Chase	Frank Mak	imbatman	Jens Hoppe
Donald Gerbracht	Frank Sleeuwaert	imstarryeyed	Jens Nerup
Doug Henderson	Fredrik Kristensen	indigoprime	Jeremy Abel
Doug Randall	Fridthjof Ollmar	Innerste	Jeremy Chappell
Douglas Acheson	Frode Solheim	Ira Selmon	Jeremy Newman
Douglas Cooper	Fuchs Joël	Ironface077	Jeroen Janmaat
Douglas Sherwood	Fumio Yokomizo	J. Alexander Jacocks	Jerome Howard
dpj5754.ks	Fur Dworetzky	JAB	Jerry Zak
DrakHo	fwrash77	Jabi Sádaba	Jerryd Perry
Drakkon20xx	Gabriel Cervera	Jace Cisnero	Jes Nørholm
Dre	GamerC64	Jack Bensted	Jesper Klingvall
	Gareth Murfin	Jacob Drecksage	Jess (@CodeSynth)

Duane Leininger II	Gareth Saxby	Jacob Rigby	Jess Anderson
Duchoslav1	Gareth Stokes	jadecar86	jesse k garson
DuncanMcB	Gary	Jadon Witt	Jesse Raasakka
dunconio	Gary Arnold	Jaidev Patel	Jesse Waldack
Dustin Alexander	Gary Henderson	Jakub Cervinka	Jester
Dustin danielsen	Gary Marsh	Jakub Smořka	jeznav
Dwayne Jarvis	Gary Paluk	Jamel Tayeb	Jim Hribar
Dylan Rutter	Gautier Nadé	James	Jim Lewis
Dylan Wolfe	Gavin Rhoades	James	Jim York
E L	George Lepir	James	Jimmy Kumpulainen
jlaalja	Juris L Purins	Lawrence Heward	Mark Brooks
Joakim Eriksson	Justin	LE	Mark Dastmalchi-Round
Joaquin Cubero	Justin	Lee Carter	Mark Dell
Jochen	Justin Butler	Lee Grocott	Mark Fastabend
Jochen Schäfer	Justin Porterfield	Lee Hibbs	Mark felton
Joe Augustine	Justin Sevakis	Lee Hobart	Mark Frischknecht
Joe MacCarthaigh	Justin Smith	Lee Johnson	Mark Harris
Joel Bianco	Justin Starr	Lee S	Mark Hawes
Joel Burnell	K.E.E.M.	Lennard voor den Dag	Mark Ian Tebbutt
Joel Chivers	Kaare Thor Olsen	Lennart Niemelä	Mark Parsons
Joel Howard	Kabi	Lennart Sorensen	Mark Smith
Johan Brostrom	Kai Tubbesing	Leo Jørgensen	Mark Usher
Johan Fonden	Kamron Rudisill	Leo Pieroni	Mark Wasfy
Johan Hallstan	Kareem Matariyeh	Leslie Bullock	Mark William Colquhoun
Johan Janssens	Karel Cibulka	Levi	Markus Becker
Johan Torneheim	Karel Millenaar	Lewis Allen	Markus Bieler-Stutz
Johannes	Karl Buckley	Lewis Bryant	Markus T
JohanP	Karl Selin	Lewis Corbett	marmacc
John	KAZUFUMI SUZUKI	Liina Vapper	Mars
John Bintz	Keith Gouveia	lioy	Martijn Bosschaart
John Brown	Keith Osborn	Loran	Martin 'Smiggy' Smith
John Chadwick	keithbuswell	Lord_rover	Martin Algora
John D'Ausilio	Kelan Smith	Louie Dimovski	Martin Caine
John Daldry	Ken Rosman	Louis Alley	Martin Cummings
John Fleming	Ken Torbeck	Luca Ruella	Martin Erhardsen
John Lomax	Kendrick Hughes	Lucas	Martin Hoffesommer
John Mineur	Kendy Peim	Luis Navega Teles	Martin Ravensholt
John O'Neill	Kenn van Hauen	Luis Viant	Martin Russell
john paino	Kenneth Christensen	Luka Zagrajsek	Martin Sonneleitner
John Schilling	Kenneth E. Lester, Jr.	Lukas Hinterleitner	Martin Wilkinson
John Schulenburg	Kenneth Hagen	Lukas Remis	Mateo Gomez
John Seuters	Kenneth Pedersen	Luke Cummins	Mateusz Przybylski
John Swanson	Kenneth Slessor	Luke Philpots	Mathias Freimann
John Thunø Hansen	Kevin Brice	luke wood	Mathieu Cartoixa
John Ward	Kevin Bullock	luthor112	MathMagic
John, Fan Wing Chun	Kevin Dietz	Lynton Kemp	Matt
JOHNG379	Kevin Fugate	MacEffects, LLC	Matt
Johnny Gallagher	Kevin Gonzalez	Mackenzie Kosut	Matt
Johnny Johannesson	Kevin J Baird	magictom1	matt myers
Johnny Suarez	Kevin Lane	Magne Dyrnes	Matt Ownby
Jon B	Kevin Leah	Magnus Wild	Matt Richenburg
Jon Guidry	Kevin Mayes	Malakie	Matt Shively
Jonas Minnberg	Kevin S.	Mansour Alghamdi	Matt Sponsler
Jonathan Abston	Kevin Wilson	Manuel Friedrich	Matthew Drew
Jonathan Anderson	kgiles	Manuel Laflamme	Matthew Farmer
Jonathan Dale	Khalid Yousif	Manuel Thannheiser	Matthew Fletcher
Jonathan Fanti	Kidofthe80s	Manuel Worschech	Matthew Hagerty
Jonathan Frederickson	Kieran Masterton	Marc	Matthew Kott
Jonathan Harden	Kilokahn	Marc Osswald	Matthew Santos
Jonathan Pratt	Kino	Marc Rifkin	Matthew Whitt
Jonathan Schmidt	Kivanc Arman	Marc Woodbridge	matthew wolf
Jonathan Steeber	KJ_AWY	Marcel Beringer	Matthias Müller
jonathan wickett	Kjetil	Marcel Schoen	Mattias Irving
Jonathan Wrigley	knoxieman	Marcel Vít	Mattias Karlsson
Joscha Metze	Knut arne bjørge	Marcin Spoczynski	Mauricio
Jose Cardoso	Konig-Wolf	Marco	Mauricio Escobar
Jose Luis Equiza	Kris Wacławski	Marco	Max Sandholm
Joseph	Kristian André Kvande	Marco Van Den Hout	Maxi
Joseph H Nonnast	Kristian Netland	Marcos Cerqueira Lima	MDrake42

Joseph Merz	Krisztian Lanyi	Marcos Kurten Michels	Megan
Joseph Rast	Krzysztof Jastrzębski	Marcos Mireles	mfmisterbe
Joseph Sherman	Kurt K	Marcus Custodio	Mia
Joseph Shivak	Kyle Good	MarekS	Miasmark
Joseph Tyson	Kyle Mendenhall	Maria Engström	Micah Stradling
Josh Brandt	kz	Marien Kaptein	Michael
Josh Litherland	L	Mario Pfeiffer	Michael
Josh Nan	Lane Chapman	Mario Robben	Michael "Zemich" Hansen
Joshua Clarke	Lari Kukkonen	Mark	Michael Bannister
Joshua Kohn	Larry Pilon	Mark	Michael Beecham
Joshua Pearson	Lars Gramkow Nielsen	Mark A. Andrews	Michael Brown
Journich	Lars Ivar Haave	Mark Abraham	Michael Crowe
JT	Lars Klaeboe	Mark Aherne	Michael Ekstrøm
Juan Manuel Pérez Mañogil	lars@tay-thomsen.dk	Mark Bean	Michael Fialkowski
Julian cleary	Lasse Wæhle	Mark Boulding	Michael Fong
Michael Hoskins	Nik Outchunis	Peter van den Hout	Robert Manleitner
Michael J. Mika	Nils Kopal	Petr Mazanec	Robert Taylor
Michael Karr	NilsBorsboom	Petri Kukko	Robin van der Hoeven
Michael Kennedy	Nima Zeighami	Petros Amoiridis	Rodney Carter
Michael Klucher	NIMBORG	Phil Hellary	Rodney Xerri
Michael Mills	noizex	Philip Campbell	Roger Brookes
Michael North	Norihisa Jyounotuka	Philippe Giordan	Rolf Wiegand Storgaard
Michael Pressler	Norman Fair	pierre kressmann	Ronald
Michael Shaw	Norman Zoschke	Pieter	Ronald Browand
Michael Slaughter	NormanC	Pieter Danhieux	Ross
Michael Troelsen	Nuigurumi	Piotr	Ross Lovell
Michael Wallen	Nunux007	pitfallharry	roy rainbolt
Michael Weathers	Nyek	PJ	Rupert L
Michal Kracik	Obraxis	Playing Curiousities	Russell
Michal Polak	Ogotay	Ponlork Heng	Russell Barber
Michciu	Ohverture	Povl Odgaard	Russell Greenwood
MichelBrissette1970	Old Bean	previousaddress	Russell Pooley
Michele Di Paola	Oliver	R Raymond	Ryan Gilmour
Mickey Miller	Olivier Latignies	R. Hwan Cho	Ryan Maki
Miguel Mendez	Omar Zorrilla	Rainer Koschnick	Ryan O'Malley
Miguel Salazar	Omega	RajelAran	Ryan Shoppo
Mika Hoffren	Omega Xi	Ralf Pösch	S. Fernandes
Mike Bliss	Onno Feringa	Ralph Egas	Saif al-Badri
Mike Gilroy	Osmund Grov	Randall Burgess	saipaman
Mike Hellyer	Otto Normalverbraucher	Raven	Salih Albayrak
Mike MacCulloch	Owen Dias	Remi Giroux	Sam Grech
Mike Powell	Øyvind Reuter Dahl	Rena	Samson Sando
Mike Thorpe	P Smith	René Pedersen	Samuel Corradi
Mike Yount	p. robinson	Rene Pindbo	Samuel Greenfeld
Mikel	Pål Kristiansen	reppel	Samuel Kielek
mln	Panxatony	RetiredNightOwl	Sarmad Gilani
mmt	Paolo Mirabella	Retro Chris	Sascha Steinert
Montana Arble	Paracelsus	retroboi	Sasha
More Bits	Pat Breen	RetroNerd	Sawf
msaw98 (aka Kiriakos Savvidis)	Pat McCormick	RetroOppa	sceptic
MustaMike	Patrick Crocoll	Rev. Christoph "Elgaroo"	SCHWALGER
mutmutmut	Patrick Devine	Brenza	Scott Duensing
MWPhillips	Patrick Dowling	RevGra	Scott Emmett O'Donnell
My Retro Computer Ltd	Patrick Falso	rhys clement-evans	Scott Evans
Mysil Rævsprekken	Patrick Mullins	Ricardo Sardo	Scott Gildersleeve
n	Patrik Kullman	Richard Baker	Scott M. Rosenberg
N	Patrik Rosenhall	Richard Barnett	SCott Muchow
Nacho Disk	Paul	Richard Boyce	Scott Reiter
Namae-san	Paul	Richard Brett	Scott Underwood
NAOKAZU SEKI	Paul	Richard Carmichael	Scott Wendt
Nate Trost	Paul Adams	Richard Grant	Scott Whiteford
Nathan Kuenzig	Paul Applegarth	Richard Hallas	Scott Whiteford
Natoli	Paul Blakeley	Richard Hunter	Sean Casey
Nefhril	Paul Brookfield	Richard King	Sean Hando
Neil Beadle	Paul Dale	Richard Lyne	Seán Hennessy
Neil Breeden	Paul Grant	Richard Mills	Sean Sackett
Neil Gourley	Paul Keward	Richard Murphy	Sean Taft
Neil Harvey	Paul Laycock	Richard Schmidbauer	Sean Williams
	Paul Liggett	Richard StClair	Sean Zoltek

Neil Irvine	Paul N Merchant	Richard Tossey	Selcuk Anilmis
Neil Stratford	Paul Stewart	Richard Troupe	SePh1r0tH
Neil Tanis	Paul Trouton	Richard Vallender	Serafeim Maroulis
Neil Watt	Paulibus Schumann	Richard Wilson	Sergei Fedulov
NeilB	Paweł Dziennik	Richard Witte	sergio escalante
Niall Pain	Pedro Rocha	Richard Yetzes	Sergio Mosca
Nicholas Macey	Per Zetterlund	Rick Felice	Seth Marinello
Nicholas Vane	Pete	Rikard Nilsson	Shane Benting
Nichole	Peter Atkin	Rob	Shane Keulen
Nick	Peter Giese	Rob Barlow	Shane Marnley
Nick Cameron	Peter Harcoff	Robert	Shawn Neff
Nick Horstmann	Peter Isaksson	Robert Burns	SHIGERU YATABE
Nick L	Peter Jaeger	Robert Chacko	Shiro Masuda
Nick Myer	Peter James	Robert Cooper	Si C
Nick Neely	Peter McQuillan	Robert Demers	Sigurjon Tomasson
Nick Winther	Peter Membrey	Robert Dillon	SigynX1
Nicolas	Peter Scoles	Robert Kernick	Simo Turkia
Niels Riis	Peter Stegemann	Robert Kreese	Simon - André Ellingsen
Nigel French	Peter Surma	Robert Lee	Steve Plunkett
Nightdive Studios	Peter Tushar	Robert M.R. Cunningham	Steven
Simon Allan	techore	Volker	Steven Baker
Simon Anthony	Ted Milker	Volker Mohr	Steven F Burton
Simon Asselin	telezoic	vonDorffy	Steven Ferenc
Simon Mok	Terry Foley	Vu	Steven Holmes
Simon Parker	The Collector	W	Steven Jeffery
Simon Read	The Creative Fund by	waffle911	Steven Kaskinen
Simon Richardson	BackerKit	Wallace Winfrey	Steven Korvin
Sinisa Jurisic	Thierry Cardon	Walter Smart	Steven Lyon
Skelebob124156	Thierry Deval	Wayne Bushby	Stewart Dunn
snz138	Thomas Claus	Wearwolf	Stirling Brinner
Socrate20000	Thomas Cornyn	webnerd	Stoeckchen
Soichiro Fujimoto	Thomas Fuchs	Wes Bachman	Stormur
Sophie Haskins	Thomas Hagen Johansen	Wes Brown	Strelowkey
SPOOke	Thomas Hargreaves	Wesley Brown	Struan Wilkie
Sprudel	Thomas Heimann	Will Green	Stu Dennison
Ståle Kopperud	Thomas Johansen	Will Harris	Stuart Dunfield
Stan Liu	Thomas Mundar	William Bain	Stuart Ingram
Starius	Thomas Niemann	William Cass	Stuart Payne
Station Ventures, LLC	Thomas Peter Berntsen	William Chrapcynski	sunny01
Steen Nord	Thomas Pfund	William McKinley Grace	Sverre Svenningsen
Stefan Friedt	Thomas Porsborn	William Phinazee	swagneto
Stefan Niestegge	Thomas Seliger	William Steele	Symphony
Stefan Svellingen	Thomas the Tank Engine	Wlodek Bielski	Tarjei Solvang Tjønn
Stefan Szomraky	Thomas Thorberger	Wolfram Riedel	Tony Miller
Steffen Jachnow	Thomas Würzler	Wouter Hermans	Torsten Johannsen
Stephan von Zitzewitz	Tiancheng Mao	xac@remus.dti.ne.jp	Tpod
Stephen	Tim	xrayssp	Travis Webb
Stephen Allen	Tim Berry	YASUHISA TAKAGANE	trekkerfou
Stephen Arthur Blower	Tim Crothers	yharaskrik	Trenton Wynter Brown
Stephen Beall	Tim Damm	Yuri David Borsato	Trevor Dickinson
Stephen Bines	Tim Dennie	Zark	Trevor Thomas
Stephen Elliott	Tim Hanson	zawadiaka	Trey Schroeder
Stephen Ferguson	Tim Nickerson	Zelle Marcovicci	troy
Stephen Gerzack	Tim Poulsen	zirconmusic	TS
Stephen Gilroy	Tim Ruggieri	前原 清隆	TurboRookie
Stephen grubb	Tim W.	堀田 英邦	twixn
Stephen Marshall	Timothy Faloon	徳昭 高崎	Tyler Colgett
Stephen McDermott	Timothy Gilchrist	志塚 勝彦	Ultrastorm77
Stephen Mills	Tobias Stening	Sebastian Greiner	Valentin Ehlert
Stephen Mulrooney	Todd Bowling	Sébastien	VampireBanana
Stephen Nuthall	Tom Arnold	Steve Opensha	Vanderheyden Franck
Stephen Orlando	Tom Bradshaw	Tommy Frössman	Varun Mehta
Stephen Pope	Tom Commis	Tony Lindberg	Veotax
Stephen Walsh	Tom Mysliwiec		viktor
Stephen Wright	Tom Richard Knudsen		Ville Kovero
Steve Hodson	Tom Stepleton		Ville Laustela
Steve James	Tomasz Berlak		Virtual Davey
Steve Mumford			VOGEL

Chapter 20:

My Patreon's

This is a list of ALL my Patreon's that have at least contributed once but also a lot of whom have supported me for years and once again without their support this monitor would not exist. Thank you.

10MinuteAmigaRetroCast 50_SHADES_OF_BEIGE Aaron Wald Adam Membry Ady Bolton Al Stremming Alain Riou Alan Anthony Alan Day Alan Gray Alan Haynes Alex Alex Chaney Alex Knapik Alexander Facchini Alvin Franklin Anders Nielsen Andre Breiler André Cocuccio Andreas Micklei andreas wheeler Andrew Costin Andrew Testa Andrew Testa Andy Libeck ANE-ZWNBS Anthony Ball Arkadiusz Bronowicki Arkadiusz Kwaśny Arttu Kärpinlehto Artur Skoczek Ashley Dawson Azura Bayta Barkbit Barry Porch Bo Ståle Kopperud Brad Hansen Brett Lamb Brian Gosney Brian John Robinson Brian Lewis Brian Sallee Brock101 James Alston James Crewe James Dalpiaz James Evans James Matheson James Tinmouth James Youngs Jamie White Jani Ruotsalainen Jasen Rogers Jason Kadaver Jean-Baptiste Bolcato Jeff Cooper	C Durnell Carl Parkes Carsten Lervad cathers Chance Davis Charles Paek Chris Copperwheat Chris Corkin Chris Doig Chris Forrester Chris Hooper Chrissy Christian Dannie Storgaard Christian King Christian Kortemeier Christopher Baker Christopher Fraser Christopher Stokes Christopher White Colm McCallion D B D. 'Xalior' Rimron-Soutter Dag J. Danger Close Digital Danial Phillips Daniel Collin Daniel McMillin Daniel Whitehead Darren Darren Johnstone DATADOG_UK Dave Koelman Dave T David David Baisley David Ferguson David Ferguson David J Leto David James Wright David Rioux David Stevenson Lennart Sorensen Leon Seremelis Lewis Bryant litwarski LIV2 Lukas Peruzovic Magne Karlsen Magne Karlsen malcolm harvey Marco Rolappe Marco Tavian Marek Grabowski Maria Engström Marie Ekeberg Mark	Derek fellowes Derek Hofmann Dick van Ginkel Dominic Demarinis Sr. Dominik Cupała Dorgorg Duane Leininger II Duncan Walker Edro Ferreira Edvin Helland elfire Enrico Ehrich Eric Erik Erik Fasih Rehman fastrobplus Folkert de Gans Frank Kemps Fredrik Rambris Gabriel Gary Broadhead gjoken Gordon.Osborne Graeme Gregory Graham Shaw Graham Sivill Graham Telfer Greg S. Gregory Hayes Grecia Mahlay Gunnar Kristjansson Gunnar Wretling Guy Black Hank Moody Hayden Brown Ian Bremner Ian Cross Ilmari Kuula Indie Carmayne Jace Fuse Jácint Zsolt Juhász Jack Frost Jake Worrell Mirko Zaccagni Miroslaw Zurek Monkat MsMadLemon Nagy Tibor Nathen Nick L Nigel French Nils Egil Lie Noland Studios Obraxis OHRM Oil of Hope
---	---	--

Jeri Mason	Mark 'Kurbeco' Simpson	Oliver Radford
Jes Nørholm	Mark Adams	Olivier Latignies
Joe Tom Collins	Mark Anthony Breckell	Paolo Mirabella
Johan Smolinski	Mark Casteleijn	Patrick Fitzgerald
Johannes Lundberg	Mark Walker	Patrick Martin
John Adams	Mark Wright	Paul A Reed
John Cummings	Markus Siegemund	Paul Chambers
John Martorana	Marshall Kiker	Paul Moore
John Træholt	Martin Cummings	Pete Morgan
Jon Steinar Kvaale	Martin Erhardsen	Peter Heginbotham
Jonas Thorell	Martin Lindholm	Peter Membrey
Jonathan Patterson	Martin W	Petri Käpylä
jonathan Wickett	Martin Wilkinson	Phil Clark
Josh Adams	maryoosh_k	Philippe Giordan
Josh Nan	Mathieu	R5D4
Jost80	Mats W	Raging Orlando
Justin Cremin	Matt Richenburg	Ralph Egas
Karl Hamilton	Matthew Fletcher	Randy J Renfrow
Kaz Redclaw	Matthew McGee	Rasmus Maagaard
Keith Symonds	Matthew Moebes	RavenX-1
Ken Lester	Mattias Karlsson	Ray Niblock
Kendrick Hughes	Mattie Whittle	Renee Cousins
Kenneth Christensen	mattsoft	Retro Roamer
Kenneth Hagen	mattyhochs	Retrofletch
Kenneth Sivertsen	ME	RetroPanic (AmigaSwiss)
Kevin Leah (AKA Zoinks!)	Michael Jurisch	Reuben Barnett
Kevin Swarts	Michael Lenardon	Richard Brayshaw
Kieran Masterton	Michael Parson	Richard Nicholls
Kim Jensen	Michael Schluetter	Richard O Keeffe
KipV	Michael Wallen	Richard Prokesch
Lane Denson	Michal Knapczyk	Richard Shears
Larry Garlock	Michel-Alexandre Fragos	Richard Statham
Lars Rabech	Mike Stimpson	Richard Yetzes
Lars Vonhof-Hunold	Mikko Kumpunen	Riot Retro Gaming
Lemaru	Thomas Brown	RMC – Neil
Lennart Niemelä	Thomas Mundar	RobD
Robert Diggle	Thomas Pfund	Starius
Robert Downs	Thomas Thorberger	Stefan Reinauer
Robert Harrison	Thor Warenskjold	Steffen Jachnow
Robert Neil	Tim	Stephen Bruce
Robert Smith	Tim Johnston	Steve Chinnock
Robin Freebeard	Tim Morgan	Steve Furniss
Robin Van Der Hoeven	Tobias Bellinder	Steve Hawkes
Robsoft	Todd Gill	Steve Korell
Rodney G. Carter	Tom Kiddy	Steve Openshaw
Rolf Hass	Tom Meades	Steven Kearns
Ronny Øvereng	Tom Richard Ingerøyen	Stig Olav Fossdal
roushimsx	Tony Escobar	Suhaib Sufi
Roy Gillotti	Tor E Hansen	Survivor Films Ltd.
Roy Griffiths	Viktor Soponyai	Sven Brönstrup
Russell Billingsley	Vincent Taylor	Tarjei S. Tjønn
S Kavanagh	Virtual Dimension	teddles
Sascha Löffler	vonDorffy	Terry C.
Sascha Wintz	Wai Tao	
SavageMind	Walter Smart	
Scot Beachell	Wayne Booker	
Scott Campbell		
Scott Wendt		
Scotty		
Sea Drive		
Shawn Bruce		
Siana Gearz		
Sigbjørn Holmvik		
Simon Foster		
Simon Lee		
Simon Marston		
Simon Zerafa		
slr nuttall		

Main companies involved

Whilst this product was conceived and designed in the UK by myself and Appy, we could not have done it alone. As you can tell, to keep this product price as reasonable as I could I had no choice but to go to China, a country that I am really starting to like and the people have my respect for their work ethic and honest way of doing business.

HLH ProtoTypes

First company is HLH ProtoTypes in Shenzhen who are really a prototyping company as the name suggests but are so much more. They helped with the original case products that also make but this time they are handling all of the plastics, metalwork and even the assembly of the monitors.

Biggest thanks go to Sara and Ronny, Sara who is my project manager in China and Ronny the cad designer and production man who has helped with my designs throughout. To be clear, these are not their Chinese names but most company staff who deal with foreign companies adopt a European name to make life easy.




Jingxin Quartz Technology

This company was picked as they have been making controllers for TV's and Monitors for a long time and they had the experience and the base technology we needed for the Slot-0 main controller board with the AV input.

But on top of this, they were prepared to work with this crazy British company with a mad idea and support us. Obviously monetary incentives helped, but they went beyond the call of duty integrating their technology in to Slot-0 and making our multitude of prototype stages.

Thank you to all especially Mr Lee and James for their support of this project throughout this long process.



Alphabetical Index

12 Volt Supply Connector.....	61
15khz.....	27
5 Volt Supply Connections.....	61
5 Volts Main Interconnect.....	64
A thank you message to all involved in this project.....	117
Appy's Retro Scalar.....	7, 26, 34
Appy's Technical section.....	47
Aspect Ratio.....	13
Assembling.....	41
Audio.....	67
Audio Connections.....	59
Audio phono output.....	20
Auto Scan.....	11
AV1/AV2.....	49
Backlight For Panel.....	64
Backlight strobing.....	28
Backplane Headphone Socket.....	63
Button Bar Connections.....	58
Button Bar for Controller.....	64
CGA.....	19
Channel (VGA).....	12
Checkmate iMIGA 3k.....	26, 40
Colour.....	67
Component.....	18
Component Video.....	65
Composite 2 and 1.....	66
Composite Video/Audio.....	15
Connections To All Slots.....	65
Contents.....	3
Controlling the NodeMCU.....	37
Day to Day usage.....	10
Design.....	24
Disassembling.....	41
Display Info.....	11
EGA.....	19
External VGA input.....	31
External VGA input on Slot 0.....	19
Form and Function.....	24
Frame rate.....	27
Front Panel Button Interface.....	50
Front power button.....	32
Future.....	28
Future features in the pipeline.....	27
GBS-C Connections.....	58
GBS-Control Node.....	36
HDMI connectors.....	21

HDMI out.....	75
HDMI Output.....	31
HDMI Switcher version.....	33
HDMI2 In.....	49
Header To Mezzanine PCB.....	48
I2C_SDA and SCL.....	69
Important information for getting started.....	9
Input Source.....	11
Inputs/Outputs selection and explanation.....	15
Internal Connector.....	62
Introduction.....	7
IR_IN.....	69
Kickstarter Backers.....	118
Latency.....	27
LVDS Interface.....	50
Meet Appy.....	111
Mezze boards.....	32
Mezze Interface.....	54
MiSTer FPGA.....	26
Modular System.....	24
Monitor POD Design.....	70
Mono-Colour Selection.....	56
Mounting Hole to Fix to Monitor Rear POD Plate.....	71
On-board Connections.....	53
Other Menu Options.....	14
Outputs selection and explanation.....	15
Overall Template POD 3D Look.....	75
Overview.....	7
Overview of the monitor features.....	24
Panel & Button Bar Connections.....	58
Panel Back Light Voltage Selection.....	51
Panel Display Connectors.....	59
Patreon's.....	124
Picture Menu.....	13
Pixel blending.....	27
POD Design.....	70
POD Power From Backplane.....	72
Pods.....	26
Power.....	11
Power connector.....	31
Power Indicator LEDs.....	73
Power Supply Input.....	15
Power Switch.....	32
Programming Ports.....	48
Raspberry Pi4 and Pi5 fitting pods.....	26
Raspberry Pi5.....	32
Rear Connections and Switches.....	55
Remote Control.....	10
RF Input (TV Tuner).....	17

RGBi.....	19
S-Video.....	66
SCART AV Out Selection.....	55
Scart input.....	22
Slot 0 – main controller board.....	30
Slot 0 Menu options.....	12
Sound setup.....	14
Speaker Connections.....	63
Speaker Connections Left and Right.....	51
Standby Connector.....	60
Stereo Audio phono output.....	20
Stereo headphone jack.....	31
Stereo Headphone Socket.....	21
SVideo.....	17
SVideo to HDMI.....	35
SVideo/RF optional board.....	35
SYNCS.....	67
Template POD 3D Look.....	75
Time details.....	14
USB inputs.....	22, 31
User Connections.....	61
VD_CTRL-2 and VD_CTRL-3.....	68
VGA Audio in.....	20
VGA Audio input.....	31
VGA Control.....	68
VGA Set Up.....	13
VGA Switch to Connect to VGA BUS.....	73
VGA Video signals and Control.....	67
What is a Retro monitor?.....	25
Why not a CRT?.....	24
XRI – Appy’s Retro Scalar.....	51
XRI – Backplane.....	57
XRI Backplane.....	25
XRI Backplane overview.....	29
XRI Protocol Revision 1.....	62
.....	15 f., 30



CHECKMATE DISPLAYS™



